

**GRAFO DIN KOMERC D.O.O.**  
**RATNIH VOJNIH INVALIDA 9, 11211 BEOGRAD-BORČA**  
**Email: decom@beotel.net web: www.decom.co.rs**  
**Cenovnik rezervnih delova za štampače**

HP1000/1200			
OEM NUMBER	MODEL	DESCRIPTION	PRICE
RA0-1005-000	HP 1000/1200	Arm Swing	1.22
RA0-1088-000	HP 1000/1200	Fuser Gear,29T	1.00
RA0-1089-000	HP 1000/1200	Fuser Gear,17T	1.00
RA0-1094/1095	HP 1000/1200	Bushing, Pressure Roller	1.00
RA0-1154-000	HP 1000/1200	Clutch Separation Roller	1.38
RA0-1020-000			0.00
RA0-1198-000	HP 1000/1200	Delivery Roller	1.52
RF0-1002-000	HP 1000/1200	Fuser Pressure Roller(Black)	6.00
RF5-2824-000	HP 1000/1200	Fuser Pressure Roller(Red)	5.00
RF0-1003-000	HP 1000/1200	Upper delivery Roller	1.52
RF0-1008-000	HP 1000/1200	Pick up Roller	1.00
RF0-1014-000	HP 1000/1200	Separation Pad	1.00
PS-1000-ASS	HP 1000/1200	The paper rolling of	1.12
RF0-1114-000	HP 1000/1200	Lower delivery Roller	2.08
RG0-1007-000	HP 1000/1200	Ashast paper pick up	4.98
RG9-1483-000	HP 1000/1200	Transfer Roller W/Gear	6.00
RG9-1483-Gear	HP 1000/1200	Fuser Gear	1.00
RG9-1483-Bsh	HP 1000/1200	Bushing Transfer Roller	1.20
RG9-1493-FM3	HP 1000/1200	Fuser Film Sleeve(Japanese material)	1.56
RAO-1100-000	HP 1000/1200	Lever Fuser Holding Right	1.98

RAO-1101-000	HP 1000/1200	Lever Fuser Holding Left	1.98
RG9-1494-Heat	HP 1000/1200	Heating element(220V)	8.00
RG9-1493-Heat	HP 1000/1200	Heating element(110V)	8.00
<b>Laser Jet M1005mfp</b>			
RM1-2093-000	HP M1005mfp	Transfer Roller W/Gear	6.00
RM1-3955-FM3	HP M1005mfp	Fuser Film Sleeve(Japanese material)	1.56
RM1-0660-000	HP M1005mfp	Fuser Pressure Roller	5.00
RC1-2038-000	HP M1005mfp	Separation Pad	1.00
RM1-0648-000	HP M1005mfp	Separation Assembly	1.62
RC1-2489-000	HP M1005mfp	Lever Fuser Holding Right	1.98
RC1-2488-000	HP M1005mfp	Lever Fuser Holding Left	1.98
RC1-0266-000	HP M1005mfp	Pick up Roller	1.00
<b>Laser Jet P1005</b>			
RM1-3955-FM3	HP P1005	Fuser Film Sleeve(Japanese material)	1.56
RM1-4023-000	HP P1005	Transfer Roller	5.00
LPR-1008	HP P1005	Fuser Pressure Roller	6.72
N/A	HP P1005	Bushing pressure roller	1.00
RM1-4006-000	HP P1005	Separation Pad	1.62
PS-P1005-ASS	HP P1005	The paper rolling of	1.90
RL1-1442-000	HP P1005	Pick up Roller	1.00
<b>Laser Jet P1008</b>			
RM1-4023-000	HP P1008/1006/1007	Transfer Roller	5.00
RM1-4008-FM3	HP P1008/1006/1007	Fuser Film Sleeve(Japanese material)	1.56
RM1-4006-000	HP P1008/1006/1007	Separation Pad	1.62
PS-P1005-ASS	HP P1008/1006/1007	The paper rolling of	1.90
RL1-1442-000	HP P1008/1006/1007	Pick up Roller	1.00
N/A	HP P1008/1006/1007	Bushing,pressure roller	1.00

LPR-1008	HP P1008/1006/1007	Fuser Pressure Roller	6.72
<b>Laser Jet P1102w</b>			
LPR-P1102	HP P1102	Fuser pressure roller	7.36
RM1-4023-000	HP P1102	Transfer roller	5.00
N/A	HP P1102	Bushing pressure roller	1.00
RM1-4006-000	HP P1102	Separation pad	1.62
RL1-1442-000	HP P1102	Pick up roller	1.00
<b>Laser Jet P1505</b>			
RM1-4234-000	HP P1505	Transfer Roller	4.98
RM1-4209-FM3	HP P1505	Fuser Film Sleeve(Metal)Japanese Material	10.20
RL1-1497	HP P1505	Pickup Roller	1.00
RC2-1426-000	HP P1505	Separation Pad	1.62
RM1-4207-000	HP P1505	Separation pad	1.62
PS-P1505-ASS	HP P1505	The paper rolling of	1.98
RU5-0024-000	HP P1505	Clutch Separation Roller	1.44
N/A	HP P1505	Bushing, Pressure Roller	1.02
LPR-M1522-000	HP P1505	Fuser Preesure Roller	7.36
<b>Laser Jet P1560</b>			
TNR-HP1560	HP P1560	Transfer roller	4.96
LPR-P1560-000	HP P1560	Fuser Preesure Roller	7.36
RC2-1422-000	HP P1560	Paper Pick- up roller	1.00
RC2-1426-000	HP P1560	Separation pad	1.62
<b>HP1010/1020</b>			
RC1-2038-000	HP 1010/1020	Separation Pad	1.00
RC1-2048-000	HP 1010/1020	Separation Pad ARM	1.00
PS-1010-ASS	HP 1010/1020	The paper rolling of	1.16
RC1-2050/2030	HP 1010/1020	Pick up Roller	1.00

RC1-2070-000	HP 1010/1020	Lever Fuser Holding Right	1.18
RC1-2069-000	HP 1010/1020	Lever Fuser Holding Left	1.18
RM1-0658-000	HP 1010/1020	Transfer Roller, W/Gear	6.00
RM1-0660-000	HP 1010/1020	Fuser Pressure Roller	5.00
RC1-2094-000	HP 1010/1020	Fuser Delivery Assy	1.56
RC1-2051-000	HP 1010/1020	Delivery Roller	1.56
RU5-0184-000	HP 1010/1020	Clutch Separation Roller	1.44
RU5-0185-000	HP 1010/1020	Fuer Gear 29T	1.00
RC1-2079-000	HP 1010/1020	Bushing Pressure Roller	1.00
RC1-6224-000	HP 1010/1020	Top Cover Fuser	12.00
RM1-3416-000	HP 1010/1020	Sensor	4.30
RM1-1493-FM3	HP 1010/1020	Fuser Film Sleeve(Japanese material)	1.56
RM1-0656-HEAT	HP 1010/1020	Heating element 220V	8.00
N/A	HP 1010/1020	Heating element 110V	8.00
RM1-0648-000	HP 1010/1020	Separation Assembly	1.62
<b>HP1022/3050</b>			
RC1-5568-000	HP 1022	Lever Fuser Holding Right	1.86
RC1-5567-000	HP 1022	Lever Fuser Holding Left	1.86
RC1-2489-000	HP 3020/3050/3055	Lever Fuser Holding Right	1.86
RC1-2488-000	HP 3020/3050/3055	Lever Fuser Holding Left	1.86
RC1-6224-000	Laser Jet 1010/M1005/1020	Top Cover Fuser	12.00
RM1-3416-000	Laster jet 1010/1020	Sensor	4.30
RC1-2050-000	HP 1022/3050	Pick up Roller	1.00
LPR-1022	HP 1022/3050	Fuser Pressure Roller	5.00
RC1-2094-000	HP 1022/3050	Delivery Roller	1.56
RC1-2051-000	HP 1022/3050	Delivery Roller	1.56
RU5-0184/0183-000	HP 1022/3050	Clutch Separation Roller	1.44
RC1-2079-000	HP 1022/3050	Bushing Pressure Roller	1.00
RM1-1493-FM3	HP 1022/3050	Fuser Film Sleeve(Japanese material)	1.56

RM1-0656-HEAT	HP 1022/3050	Heating element(220V)	8.00
N/A	HP 1022/3050	Heating element(110V)	8.00
PS-1022-ASS	HP 1022/3050	The paper rolling of	1.24
RC1-5564(RM1-2048)	HP 1022/3050	Separation Pad	1.00
RC1-5564-ASM	HP 1022/3050	Separation Assembly	1.62
RC1-5563-000	HP 1022/3050	Separation Pad	1.00
RU5-0523-000	HP 1022/3050	Fuser Gear 37T	1.00
RM1-0658-000	HP 1022/3050	Transfer Roller W/Gear	6.00
<b>HP1100/3200</b>			
RF5-2832-000	HP 1100/3200	Separation Pad	1.00
RY7-5050-000	HP 1100/3200	Separation Pad Kit	1.30
RF5-2886-000	HP 1100/3200	Separation Pad ARM	1.00
RS5-2502-000	HP 1100/3200	Spring for Separation Arm	0.26
PS-1100-ASS	HP 1100/3200	The paper rolling of	1.16
RB2-4026-000	HP 1100/3200	Pick up Roller	1.00
RB2-3912-000	HP 1100/3200	Feed Roller	1.36
RB2-3949-000	HP 1100/3200	CAM,Pickup Roller	1.00
RG5-4585-000	HP 1100/3200	Pick up Assembly(37T)	1.64
RF5-2830-000	HP 1100/3200	Roller, Face Down	2.08
RF5-2822-000	HP 1100/3200	Roller, Face up output	1.70
RF5-2823-000	HP 1100/3200	Fuser Pressure Roller	6.00
RG5-4589-FM3	HP 1100/3200	Fuser Film Sleeve(Japanese material)	3.20
RG5-4589-heat	HP 1100/3200	Heating element(110V)	10.00
RG5-4590-HEAT	HP 1100/3200	Heating element(220V)	10.00
RG5-4657-000	HP 1100/3200	Transfer Roller, W/Gear	6.00
RB2-3956/3957	HP 1100/3200	Bushing ,Pressure Roller	1.21
<b>HP1320/1160</b>			
RC1-3654-000	HP 1320/1160	Delivery Roller	2.08
RM1-1298-pad	Laser 1320/1160/2420	pad only, Separation	1.50

RM1-1298-ASSY	Laser 1320/1160/2420	Separation Pad Assembly	5.30
RL1-0540-000	HP 1320/1160	Paper Pick up Roller Tray2	1.46
PS-1160-ASS	HP 1320/1160	The paper rolling of	2.48
RB2-2891-000	HP 1320/1160	Pick up Roller	1.20
RM1-1471-000	HP 1320/1160	Transfer Roller,	6.00
RC1-3630-000	HP 1320/1160	Fuser Pressure Roller	8.00
DP-1320-000	HP 1320/1160	Delivery Roller	1.86
RC1-3691-000	HP 1320/1160	Pick up Roller	1.70
RU5-0331-000	Laser 1320/1160/2420	Gear 29T, Lower Roller	1.00
RU5-0325-000	HP 1320/1160	Clutch Separation Roller	1.44
RM1-1301-000			0.00
RC1-3471-000	HP 1320/1160	Roller,Pick up Cam	1.00
HR-1320-000	HP 1320/1160	Roller holder 24/18T	1.00
RC1-3616-000	HP 1320/1160	Lever Fuser Holding Right	1.14
RC1-3617-000	HP 1320/1160	Lever Fuser Holding Left	1.14
RC1-3575-000	HP 1320/1160	Arm Swing	1.64
RC1-3612-000	HP 1320/1160	Exit Guide Fuser Lower	11.52
RC1-3612-000	HP 1320/1160	Exit Guide Fuser Lower(SET)	16.46
RM1-1461-FM3	HP 1320/1160	Fuser Film Sleeve(Japanese material)	1.56
RC1-3610/3609	Laser 1320/1160/2420	Bushing Pressure Roller (Grey color)	1.20
RC1-3610/3609	Laser 1320/1160/2420	Bushing Pressure Roller (Green color)	1.40
N/A	HP 1320/1160	Heating element(220V)	9.00
RM1-1461-HEAT	HP 1320/1160	Heating element(110V)	9.00
<b>HP M1522mfp</b>			
RL1-1497	Laser Jet p1505/M1522	Paper Pick- up roller	0.56
RC2-1426-000	Laser Jet p1505/M1522	Separation pad	1.62
PS-P1505-ASS	Laser Jet p1505/M1522	The paper rolling of	1.98
RM1-4207-000	Laser Jet p1505/M1522	Separation pad	1.62
N/A	Laser Jet p1505/M1522	Bushing pressure roller	1.20

N/A	Laser Jet p1505/M1522	Heating Element 220V	9.00
N/A	Laser Jet p1505/M1522	Heating Element 110V	9.00
TNR-HP1522	HP M1522mfp	Transfer Roller	4.98
RM1-4209-FM3	HP M1522mfp	Fuser Film Sleeve(Metal)Japanese Material	12.00
LPR-M1522-000	HP M1522mfp	Fuser Preesure Roller	9.00
<b>HP M1536DNF</b>			
LPR-M1536DNF	ProM1536DNF/P1606	Fuser Preesure Roller	9.00
N/A	ProM1536DNF/P1606	Heating Element 220V	9.00
N/A	ProM1536DNF/P1606	Heating Element 110V	9.00
N/A	LaserJet ProM1536DNF	Bushing pressure roller	1.00
RM1-4023-000	LaserJet ProM1536DNF	Transfer roller	7.00
RL1-1497-000	LaserJet ProM1536DNF	Paper Pick- up roller	0.56
RM1-4207-000	LaserJet ProM1536DNF	Separation pad	1.80
<b>HP 2015</b>			
RM1-1461-FM3	HP 2015/1160	Fuser Film Sleeve(Japanese material)	1.56
RU5-0331-000	HP 2015/1320	Gear 29T, Lower Roller	1.00
RC1-3471-000	HP 2015/1160	Roller,Pick up Cam	1.00
RU5-0325-000	HP 2015/1160	Clutch Separation Roller	1.44
RM1-1301-000	HP 2015/1160		0.00
RC1-3610/3609	HP 2015/1320	Bushing, Pressure Roller	1.20
RC1-3616-000	HP 2015	Lever Fuser Holding Right	1.14
RC1-3617-000	HP 2015	Lever Fuser Holding Left	1.14
RM1-1298-pad	HP 2015/1320	pad only, Separation	1.28
RM1-1298-ASSY	Laser 1320/1160/2420	Separation Pad Assembly	5.30
RB2-1524-000	HP 2015/5200	Separation Pad Tray1	1.00
RL1-1525-000	HP 2015/2400	Pick up roller	1.00
PS-P2015-ASS	HP 2015/5200	The paper rolling of Tray1	1.30
RB1-2891-000	HP 2015	Paper Pick up Roller Tray2	1.00
RL1-0540-000	HP 2015	Paper Pick up Roller Tray2	1.46

RC1-3654-000	HP 2015/1160	Delivery Roller	2.08
RC1-3575-000	HP 2015	Arm Swing	1.64
RM1-4279-000	HP 2015	Transfer Roller	5.00
RC2-0300-000	HP 2015	Guide Upper Delivery	8.38
DP-1320-000	HP 2015/1160	Delivery Roller	1.86
LPR-2015	HP 2015	Fuser Pressure Roller	9.00
RU5-0302	HP 2015	Fuser Gear	2.14
RL1-0568-000	HP 2015/2420	Pick up Roller Tray1	1.00
<b>HP P2035</b>			
LPR-P2035	HP P2035	Fuser pressure roller	8.40
RM1-6450-000	HP P2035	Transfer Roller	4.94
RU5-0325-000	HP P2035	Clutch separation roller	1.44
RC1-3471-000	HP P2035	Roller,Pick up Cam	1.00
RM1-6405-FM3	HP P2035	Fuser Film Sleeve(black inside and outside)	2.30
N/A	HP P2035	Fuser gear 27T	1.18
RL1-2120-000	HP P2035	Pick up roller	1.00
RM1-6414-000	HP P2035	Paper Pick-up roller Tray2	3.00
PS-P2035-ASS	HP P2035	The paper rolling of Tray2	4.34
N/A	HP P2035	Heating Element 220V	9.00
N/A	HP P2035	Heating Element 110V	9.00
N/A	HP P2035	Bushing pressure roller	1.24
RM1-6397-000	HP P2035	Separation pad	1.50
<b>HP 2100</b>			0.00
RG5-4164-000	HP 2100	Transfer Roller, w/Gear	6.00
RF5-2601-000	HP 2100	Fuser Pressure Roller	8.00
RB2-2973-000	HP 2100	Bushing Pressure Roller	1.00
RG5-4132-FM3	HP 2100	Fuser Film Sleeve(Japanese material)	3.20



RB2-2900-000	HP 2100	Pick up Roller, mp tray	1.00
RB2-2838-000	HP 2100	Separation Pad ,Tray1	1.00
RB2-3008-000	HP 2100	Separation Pad, Tray2	1.00
RB9-0695-000			0.00
RB2-2835/6348	HP 2100	Separation pay ,Tray1	1.00
PS-2100-ASS	HP 2100	The paper rolling of Tray2	1.72
RB2-2891-000	HP 2100	Pick up Roller	1.00
RB2-2892-000	HP 2100	Roller, Guide	1.00
RB2-2851-000	HP 2100	Upper Delivery Roller	2.08
RG5-4156-000	HP 2100	Gear assembly,drive	1.44
RB1-2190-000	HP 2100	Clip pick up	1.00
RS6-0443-000	HP 2100	Fuser Gear(15T)	1.00
RS6-0442-000	HP 2100	Fuser Gear(14T)	1.00
RS6-0458-000	HP 2100	Fuser Gear(26T)	1.00
RF5-2603-000	HP 2100	Delivery Roller Ass'y	2.08
RG5-4135-HEAT	HP 2100	Heating Element 220V	11.50
RG5-4134-HEAT	HP 2100	Heating Element 110V	11.50
<b>HP 2200</b>			
RB2-6349-000	HP 2200/2100	Separation Pad Tray2	1.00
RB2-6348-000	HP 2200/2100	Separation Pad Tray1	1.00
RF5-6254-000	HP 2200	Separation Pad Tray 1	1.00
RB2-3272-000	HP 2200	Separation Assy Tray 1	1.86
RB2-2900-000	HP 2200	Pick up Roller mp Tray	1.00
PS-2200-ASS	HP 2200	The paper rolling of Tray1	1.72
PS-2200-ASS	HP 2200	The paper rolling of Tray2	1.72
RG5-5560-FM3	HP 2200	Fuser Film Sleeve(Japanese material)	3.20
RG5-5570-HEAT	HP 2200	Heating element(110V)	11.50
N/A	HP 2200	Heating element(220V)	11.50

RG5-5581-000	HP 2200	Transfer Roller, W/Gear	6.00
RB2-2973-000	HP 2200	Bushing, Pressure Roller	1.00
RB2-6368-000	HP 2200	Fuser Pressure Roller	8.00
RB2-6372-000	HP 2200	Delivery Roller Assy	2.08
RB2-6304-000	HP 2200	Pick up Roller	1.00
RB2-2891-000			0.00
RB2-2892-000	HP 2200	Roller, Guide	1.00
RF5-3275-000	HP 2200	Delivery Roller Assy	2.08
RS6-0441-000	HP 2200	Gear 15T,Upper Delivery	1.00
RS6-0923-000	HP 2200	Fuser Gear 27T	1.00
<b>HP 2300</b>			
RC1-0954-000	HP 2300	Separation Pad	1.00
RC1-0939-000	HP 2300	Separation Pad	1.00
PS-2300-ASS	HP 2300	The paper rolling of Tray1	1.64
PS-2300-ASS	HP 2300	The paper rolling of Tray2	1.68
RB2-2891-000	HP 2300	Pick up Roller	1.00
RB2-2892-000	HP 2300	Roller, Guide	1.00
RC1-0945-000	HP 2300	Pick up Roller	1.00
RM1-0357-FM3	HP 2300	Fuser Film Sleeve(Japanese material)	3.20
RM1-0338-000	HP 2300	Transfer Roller ,W/Gear	6.00
RC1-0988-000	HP 2300	Bushing, Pressure Roller	1.00
RC1-0991-000	HP 2300	Fuser Pressure Roller	8.00
N/A	HP 2300	Heating Element(220V)	11.50
N/A	HP 2300	Heating Element(110V)	11.50
RM1-0371-000	HP 2300	Delivery Roller	2.08
RC1-0982-000	HP 2300	Upper Delivery Roller	2.08
RS6-0923-000	HP 2300	Fuser Gear 27T	1.00
RF5-4258-000	HP 2300	Separation Pad	1.96

<b>HP 2420/2400</b>			
RU5-0377/0378/0379	HP 2400	Fuser Gear (3pcs/set)	2.66
RM1-1298-pad	HP 2420/1160	pad only, Separation	1.28
RM1-1298-ASSY	Laser 1320/1160/2420	Separation Pad Assembly	5.30
PS-2420-ASS	HP 2420	The paper rolling of Tray1	1.34
PS-2420-ASS	HP 2420	The paper rolling of Tray2	2.12
RC1-0939-000	HP 2420	Separation Pad-Tray1	1.00
RL1-0542-000	HP 2420	Pick up Roller Tray 2	1.00
RL1-0568-000	HP 2420	Pick up Roller Tray 1	1.00
RM1-1531-FM3	HP 2420	Fuser Film Sleeve(Japanese material)	3.20
RC1-3969-000	HP 2420	Fuser Pressure Roller	8.68
N/A	HP 2420	Heating Element(220V)	10.56
N/A	HP 2420	Heating Element(110V)	10.56
RC1-3976-CLN	HP 2420	Guide upper delivery	16.80
DR-2400-LO	HP 2420	Delivery Roller lower	2.08
RC1-3974-000	HP 2420	Guide blade	3.46
RC1-3991-000	HP 2420	Delivery Roller	2.08
RC2-0670-000	HP 2420	Exit Guide Fuser Lower Assy	16.46
RC1-3977-000	HP 2420	Exit Guide Fuser Lower	13.14
RC1-3610/3609	Laser 1320/1160/2420	Bushing Pressure Roller (Grey color)	0.90
RC1-3610/3609	Laser 1320/1160/2420	Bushing Pressure Roller (Green color)	1.02
RM1-1508-000	HP 2420	Transfer Roller W/Gear	6.00
RU5-0331-000	HP 2420	Gear 29T, Roller	1.00
<b>HP P3005</b>			
RC1-0939-000	HP P3005	Separation Pad-Tray1	1.00
RM1-3740-FM3	HP P3005/2200	Fuser Film Sleeve(Japanese material)	3.20
RL1-0568-000	HP 2420/P3005	Pick up Roller Tray 1	1.00

RM1-1298-Pad	HP P3005	pad only, Separation	1.28
RM1-1298-ASSY	Laser 1320/1160/2420	Separation Pad Assembly	5.30
RM1-3738	HP P3005	Separation pad ASS'Y-Tray2	6.02
RC1-3976-CLN	HP P3005	Guide upper delivery	16.80
RC2-0670-000	HP P3005	Exit Guide Fuser Lower Assy	16.46
RC1-3977-000	HP P3005	Exit Guide Fuser Lower	13.14
RL1-1370	HP P3005	Pick up Roller	1.62
RM1-3537/0731	HP P3005	Pick up Roller	2.74
RM1-3763-000	HP P3005	Pick up roller Tray2	3.00
PS-P3005-ASS	HP P3005	The paper rolling of Tray1	1.34
RM1-1508-000	HP P3005	Transfer Roller W/Gear	4.98
DR-P3005-LO	HP P3005	Delivery Roller lower	2.08
RC1-3974-000	HP P3005	Guide blade	3.46
RU5-0957-000	HP P3005	Gear 20T	1.00
RU5-0956-000	HP P3005	Gear 20/20	1.00
RU5-0959-000	HP P3005	Gear 19T	1.00
RU5-0958-000	HP P3005	Gear 17/17	1.00
RU5-0964-000	HP P3005	Gear , Roller 29T	1.00
RU5-0966-000	HP P3005	Gear 20T	1.00
N/A	HP P3005	Gear 15T	1.00
RM1-3746-000	HP P3005	ElectricMotor gear 5pcs	7.56
RU5-0386-000	HP P3005	Gear	1.32
RU5-0387-000	HP P3005	Gear	1.82
LPR-3005	HP P3005	Fuser Pressure Roller	9.28
RC1-3610/3609	HP P3005	Bushing Pressure Roller (Grey color)	1.20
RC1-3610/3609	HP P3005	Bushing Pressure Roller (Green color)	1.40
<b>HP P3015</b>			

LPR-3015	HP P3015	Fuser Pressure Roller	8.90
RM1-3740-FM3	HP P3015	Fuser Film Sleeve	3.20
RM1-6321	HP P3015	Transfer Roller W/Gear	5.10
RU7-0028	HP P3015	Gear, Roller 29T	1.00
RC2-8575-000	HP P3015	Separation pad-Tray1	1.00
RM1-6397	HP P3015	pad only, Separation	1.50
RL1-2412-000	HP P3015	Pick up roller	1.00
N/A	HP P3015	Heating element(220V)	13.80
N/A	HP P3015	Heating element(110V)	13.80
N/A	HP P3015	Bushing , Pressure Roller	1.34
RM1-6313	HP P3015	Pickup Roller Tray 2	3.00
<b>HP 3010/3020/3030</b>			
RC1-2038-000	HP 3010/3020/3030	Separation Pad	1.00
RC1-2048-000	HP 3010/3020/3030	Separation Pad	1.00
RC1-2050/2030	HP 3010/3020/3030	Pick up Roller	1.00
RM1-0658-000	HP 3010/3020/3030	Transfer Roller, W/Gear	6.00
RM1-0660-000	HP 3010/3020/3030	Fuser Pressure Roller	5.00
RU5-0184-000	HP 3010/3020/3030	Clutch Separation Roller	1.44
RM1-1493-FM3	HP 3010/3020/3030	Fuser Film Sleeve(Japanese material)	1.56
RC1-2094-000	HP 3010/3020/3030	Delivery Roller	1.56
RC1-2051-000	HP 3010/3020/3030	Delivery Roller	1.56
<b>HP M3027/M3035MFP</b>			
LPR-3005	HP M3027/M3035MFP	Fuser pressure roller	9.28
RM1-3740-FILM	HP M3027/M3035MFP	Fuser Film Sleeve(Japanese material)	3.20
RC1-3610/3609	HP M3027/M3035MFP	Bushing,pressure roller	1.00
RM1-1298-pad	HP M3027/M3035MFP	pad only, Separation	1.28
RM1-1298-ASSY	Laser 1320/1160/2420	Separation Pad Assembly	5.30

RM1-0731-000	HP M3027/M3035MFP	Pick up roller	2.74
RL1-0568-000	HP M3027/M3035MFP	Pick up roller TRAY1	1.00
RU5-0964-000	HP M3027/M3035MFP	Gear , Roller 29T	1.00
RM1-1508-000	HP M3027/M3035MFP	Transfer roller W/Gear	6.00
<b>HP 4000/4050</b>			
RG5-4283-000	HP 4000/4050	Transfer Roller, W/Gear	6.44
RS5-0948-000	HP 4000/4050	Gear, Transfer Roller	1.00
RB1-8794-000	HP 4000/4050	Fuser Pressure Roller	6.72
RS5-1297-000	HP 4000/4050	Bushing Right, Pressure Roller	1.00
RS5-1310-000	HP 4000/4050	Bushing Left, Pressure Roller	1.00
RF5-1885-000	HP 4000/4050	Feed Roller	1.00
RB1-8865-000	HP 4000/4050	Pickup Roller	1.00
RF5-2484-000	HP 4000/4050	Pickup Roller ASSY	2.84
RG5-3718-000	HP 4000/4050	Pickup Roller assembly Tray1	1.00
RB1-5281-000	HP 4000/4050	Separation Pad	1.52
RB1-8773-000	HP 4000/4050	Separation pad-Tray1	1.00
PS-4000-ASS	HP 4000/4050	The paper rolling of Tray1	1.52
RG5-2660-000	HP 4000/4050	Heating element(220V)	10.58
RG5-2659-000	HP 4000/4050	Heating element(110V)	10.58
RB1-8974-000	HP 4000/4050	Torpue limier	2.54
RB1-8798-000	HP 4000/4050	Upper Delivery Roller	2.08
RG5-2648-000	HP 4000/4050	Lower Delicery Roller	1.98
RB1-8811-000	HP 4000/4050	Cam deflector	1.00
RB1-8877-000	HP 4000/4050	Coupler,pickup	1.00
RS5-8797-000	HP 4000/4050	Guide blade	2.44
RS5-0922-000	HP 4000/4050	Fuser Gear(34T)	1.00
RS5-0921-000	HP 4000/4050	Fuser Gear(33T)	1.00

RS5-0924-000	HP 4000/4050	Fuser Gear(21T)	1.00
RG5-2661-FM3	HP 4000/4050	Fuser Film Sleeve(Japanese material)	3.20
RS5-8819-000	HP 4000/4050	Fuser screw	1.00
RF5-2484-000	HP 4000/4050	Pick up Roller Assembly	2.84
RB1-2190-000	HP 4000/4050	Clip,pickup spring	1.00
<b>Laser Jet Pro M401N</b>			
LPR-M401N	Laser Jet Pro M401n	Fuser Preesure Roller	10.00
RM1-6397-000	Laser Jet Pro M401n	separation Pad	2.00
RL1-3307-000	Laser Jet Pro M401n	Pick up roller	1.00
RM1-9168-000	Laser Jet Pro M401n	Pick tire without hub	1.00
N/A	Laser Jet Pro M401n	Bushing pressure roller	1.50
<b>HP P4014</b>			
LPR-4014-LOW	HP P4014N/4015N	Fuser Pressure Roller	18.00
RC2-2432	HP P4014N/4015N	Swing Plate Assembly	12.00
RL1-1659-18T	HP P4014N/4015N	Motor Gear	2.00
RU6-0190	HP P4014N/4015N	Gear (193t)	5.30
RU6-0170	HP P4014N/4015N	Gear 25T/91T	2.00
RU6-0171	HP P4014N/4015N	Gear 33T	2.00
RU6-0172	HP P4014N/4015N	Gear 35T	2.00
RM1-4554-FM3	HP P4014N/4015N	Fuser Film Sleeve(Japanese material)	38.00
RM1-1110-000	HP P4014N/4015N	Transfer Roller Assy	8.00
RL1-1663-000	HP P4014N/4015N	Pick up roller TRAY1	1.20
RL1-1654-000	HP P4014N/4015N	Pick up roller TRAY1	1.20
RL1-1641-000	HP P4014N/4015N	Pick up roller TRAY1	1.00
RU6-0164-000	HP P4014N/4015N	Fuser gear(18T)	1.20
RU6-0165	HP P4014N/4015N	Fuser gear(17T)	1.20
RC2-2399-000	HP P4014N/4015N	Gear, Pressure Roller (32T)	1.80

BSH-4014	HP P4014N/4015N	Bushing, Pressure Roller	1.50
RM1-0036-000	HP P4014N/4015N	Pick up Roller	1.50
RM1-0037-000	HP P4014N/4015N	Pick up Roller	1.50
RC2-5208-000	HP P4014N/4015N	Fuser Guide Delivery	8.00
CVR-P4014-L	HP P4014N/4015N	cover Asm Left	8.00
CVR-P4014-R	HP P4014N/4015N	cover Asm Right	5.00
N/A	HP P4014N/4015N	Heating element(220V)	45.00
N/A	HP P4014N/4015N	Heating element(110V)	45.00
LVR-P4014-RGT	HP P4014N/4015N	Fuser Latch Clip, Right	1.00
LVR-4014-LFT	HP P4014N/4015N	Fuser Latch Clip, Left	1.00
<b>HP 4100</b>			
RG5-5295-000	HP 4100	Transfer Roller assembly	6.44
RS5-0948-000	HP 4100	Gear, Transter Roller	1.00
RB2-4919-000	HP 4100	Fuser Pressure Roller	9.00
BSH-4100-PR	HP 4100	Bushing Right ,Pressure Roller	1.00
BSH-4100-PL	HP 4100	Bushing Left, Pressure Roller	1.00
RS5-0922-000	HP 4100	Gear 34T, Pressure Roller	1.00
RS5-0677-000	HP 4100	Fuser Gear 28T	3.16
RS5-0675-000	HP 4100	Fuser Gear 14T/21T	1.00
RS5-0676-000	HP 4100	Fuser Gear 21T	1.00
RF5-3086-000	HP 4100	Separatin Pad	1.00
RG5-5281-000	HP 4100	Separatin Pad ass'y , MPTray	1.52
PS-4100-ASS	HP 4100	The paper rolling of Tray1	1.52
DR-4100-L-000	HP 4100	Delivey Roller	1.96
RB1-8877-000	HP 4100	Joint Pickup	1.00
RB2-4931-000	HP 4100	Lever Left holding	1.00
RB2-4932-000	HP 4100	Lever Right holding	1.00



RG5-5069-HEAT	HP 4100	Heating element(110V)	12.54
N/A	HP 4100	Heating element(220V)	12.54
RG5-5068-FM3	HP 4100	Fuser Film Sleeve(Japanese material)	3.20
RF5-3114-000	HP 4100	Roller ,Feed	1.00
RG5-3718-000	HP 4100	Pick up Roller Tray1	1.00
RB1-8957-000	HP 4100	Feed Roller	1.00
RB1-2190-000	HP 4100	Clip Pickup spring	1.00
RB1-8974-000	HP 4100	Torque limiter	2.54
<b>HP 4200</b>			
RM1-0037-000	HP 4200	Paper Feed Roller	1.00
RM1-0036-000	HP 4200	Paper pick up Roller	1.00
RL1-0019-000	HP 4200	Paper pick up Roller-Tray1	1.00
RL1-0007-000	HP 4200	Separation Pad-Tray1	1.00
RG5-5281-000	HP 4200	Separation Pad-Tray1	1.52
PS-4200-ASS	HP 4200	The paper rolling of Tray1	1.24
RM1-0013-FM3	HP 4200	Fuser Film Sleeve(Japanese material)	3.20
RC1-0070-000	HP 4200	Fuser Pressure Roller	14.00
RC1-0062-000	HP 4200	Fuser Guide Delivery	5.00
RC1-0387-000	HP 4200	Guide upper delivery	5.50
RU5-0016-000	HP 4200	Fuser Gear 40T	1.32
RM1-0043-GRB	HP 4200	Gear asm, Swing plate Assy	2.00
RM1-0043-060	HP 4200	Swing Plate Assembly	6.64
RB1-6588-000	HP 4200/4250	Torpue Limiter	3.46
RM1-0699-000	HP 4200	Transfer Roller Assy	5.64
RM1-0699-Gear	HP 4200	Gear, Transfer Roller	1.00
RU5-0018-000	HP 4200/4250	Fuser Gear 18T	1.24
DR-4200	HP 4200/4250	Delivery Roller	3.22

RU5-0017-000	HP 4200	Fuser Gear 27T	1.00
RU5-0020-000	HP 4200/4250	Fuser Gear 41/15T	1.00
RU5-0277-000	HP 4200	Black Swing plate Assy 41T	1.40
RC1-0387-000	HP 4200/4250	Guide Upper Delivery	5.26
RC1-0072-000	HP 4200/4250	Lower Enerance Guide	4.28
LVR-4200-LFT	HP 4200/4250	Fuser Latch Clip, Left	1.00
LVR-4200-RGT	HP 4200/4250	Fuser Latch Clip, Right(with Metal)	1.68
LVR-4200-RGT	HP 4200/4250	Fuser Latch Clip, Right	1.00
BSH-4200-LFT	HP 4200/4250	BushingLeft, Pressure Roller	1.00
BSH-4200-RGT	HP 4200/4250	Bushing Right, Pressure Roller	1.00
N/A	HP 4200/4250	Heating Element(220V) Japanese Material	31.20
N/A	HP 4200/4250	Heating Element(110V) Japanese Material	31.20
<b>HP 4300</b>			
RM1-0036-000	HP 4300	Pick up Roller	1.00
RM1-0037-000	HP 4300	Pick up Roller	1.00
RL1-0019-000	HP 4300	Pick up Roller	1.00
RG5-5281-000	HP 4300	Separation Pad	1.52
PS-4200-ASS	HP 4300	The paper rolling of Tray1	1.24
RC1-0044-000	HP 4300	Transfer Roller Assy	5.64
RL1-0024-FM3	HP 4300	Fuser Film Sleeve(Metal) Japanese Material	15.80
RC1-0070-000	HP 4300	Fuser Pressure Roller	13.22
RC1-0062-000	HP 4300	Fuser Guide Delivery	5.00
RM1-0043-GRB	HP 4300	Gear asm, Swing plate Assy	2.00
RM1-0043-060	HP 4300	Swing Plate Assembly	6.64
RC1-0165-000	HP 4300	Stop,500 Sheet Tray	1.98
DR-4200-000	HP 4300	Delivery Roller, W/Geaer	3.18
RU5-0018-000	HP 4300	Fuser Gear 18T	1.24

RU5-0017-000	HP 4300	Fuser Gear 27T	1.00
RU5-0020-000	HP 4300	Fuser Gear 41/15T	1.00
RC1-3325-000	HP 4300	Fuser Gear 40T	1.54
RU5-0277-000	HP 4300	Black Swing plate Assy 41T	1.40
BSH-4200-RGT	HP 4300	Bushing Right, Pressure Roller	1.00
BSH-4200-LFT	HP 4300	Bushing Left, Pressure Roller	1.00
LVR-4200-RGT	HP 4300	Fuser Latch Clip, Right(with Metal)	1.68
N/A	HP 4300	Heating Element(220V) Japanese Material	31.20
N/A	HP 4300	Heating Element(110V) Japanese Material	31.20
LVR-4200-RGT	HP 4300	Fuser Latch Clip, Right	1.00
LVR-4200-LFT	HP 4300	Fuser Latch Clip, Left	1.00
<b>HP 4250/4350</b>			
RM1-0037-000	HP 4250/4350	Paper Feed Roller	1.00
RM1-0036-000	HP 4250/4350	Paper pick up Roller	1.00
RL1-0019-000	HP 4250/4350	Paper pick up Roller-Tray1	1.00
RL1-0007-000	HP 4250/4350	Separation Pad-Tray1	1.00
PS-4200-ASS	HP 4250/4350	The paper rolling of Tray1	1.24
RL1-0024-FM3	HP 4250/4350	Fuser Film Sleeve(Metal) Japanese Material	18.00
RC1-0070-000	HP 4250/4350	Fuser Pressure Roller	20.00
RC1-0072-000	HP 4250/4350	LOWER ENERANCE GUIDE	5.00
RC1-0165-000	HP 4250/4350	Stop,500 Sheet Tray	1.98
GD-4250-UP	HP 4250/4350	Upper guide	3.68
RC1-3329-000	HP 4250/4350	Guide Only Delivery	4.98
RC1-3325-000	HP 4250/4350	Fuser Gear 40T	1.54
RM1-0043-GRB	HP 4250/4350	Gear asm, Swing plate Assy	2.00
RM1-0043-060	HP 4250/4350	Swing Plate Assembly	6.64
RB1-6588-000	HP 4250/4350	Torpue Limiter	3.46

RG5-5281-000	HP 4250/4350	Separation Pad-Tray1	1.52
RM1-1110-000	HP 4250/4350	Transfer Roller Assy	5.64
RM1-1118-Gear	HP 4250/4350	Transfer Roller Gear	1.00
RU5-0018-000	HP 4250/4350	Fuser Gear 18T	1.24
RU5-0044-000	HP 4250/4350	White, Swing plate Assy 51T	1.54
CVR-4250-L	HP 4250/4350	COVER ASM LEFT	5.28
CVR-4250-R	HP 4250/4350	COVER ASM RIGHT	1.98
DR-4250	HP 4250/4350	Delivery Roller	3.40
RU5-0275-000	HP 4250/4350	Fuser Gear 27T	1.00
RU5-0020-000	HP 4250/4350	Fuser Gear 41/15T	1.00
RC1-0387-000	HP 4250/4350	Guide Upper Delivery	5.26
RC1-0072-000	HP 4250/4350	Lower Enerance Guide	4.28
LVR-4200-LFT	HP 4250/4350	Fuser Latch Clip, Left	1.00
LVR-4200-RGT	HP 4250/4350	Fuser Latch Clip, Right(with Metal)	1.68
LVR-4200-RGT	HP 4250/4350	Fuser Latch Clip, Right	1.00
N/A	HP 4250/4350	Heating Element(220V) Japanese Material	31.20
N/A	HP 4250/4350	Heating Element(110V) Japanese Material	31.20
BSH-4200-LFT	HP 4250/4350	Bushing Left, Pressure Roller	1.00
BSH-4200-RGT	HP 4250/4350	Bushing Right, Pressure Roller	1.00
<b>HP 4345</b>			
RL1-0024-FM3	HP 4345	Fuser Film Sleeve(Metal) Japanese Material	18.00
RC1-3329-000	HP 4345	Guide Only Delivery	4.98
RC1-3325-000	HP 4345	Fuser Gear 40T	1.54
RC1-0070-000	HP 4345	Fuser Pressure Roller	20.00
RG5-5281-000	HP 4345	Separation Pad-Tray1	1.52
PS-4200-ASS	HP 4345	The paper rolling of Tray1	1.24
RM1-1110-000	HP 4345	Transfer Roller Assy	5.64

RM1-0043-GRB	HP 4345	Gear asm, Swing plate Assy	2.00
RM1-0043-060	HP 4345	Swing Plate Assembly	6.64
DR-4250	HP 4345	Delivery Roller	3.40
RU5-0018-000	HP 4345	Fuser Gear 18T	1.24
RU5-0275-000	HP 4345	Fuser Gear 27T	1.00
RU5-0020-000	HP 4345	Fuser Gear 41/15T	1.00
RC1-0387-000	HP 4345	Guide Upper Delivery	5.26
RC1-0072-000	HP 4345	Lower Enerance Guide	4.28
LVR-4345-LFT	HP 4345	Fuser Latch Clip, Left	1.00
LVR-4345-RGT	HP 4345	Fuser Latch Clip, Right	1.00
N/A	HP 4345	Heating Element(220V) Japanese Material	31.20
N/A	HP 4345	Heating Element(110V) Japanese Material	31.20
BSH-4345-LFT	HP 4345	Bushing Left, Pressure Roller	1.00
BSH-4345-RGT	HP 4345	Bushing Right, Pressure Roller	1.00
<b>HP M4555MFP</b>			
LPR-M4555MFP	HP M4555MFP	Fuser pressure roller	18.00
RC2-2399-000	HP M4555MFP	Fuser gear 32T	1.52
RM1-5462-000	HP M4555MFP	Transfer Roller Assy	5.80
RC1-3361-000	HP M4555MFP	Bushing pressure roller	1.06
CVR-P4014-L	HP M4555MFP	cover Asm Left	5.36
CVR-P4014-R	HP M4555MFP	cover Asm Right	3.30
RU6-0164-000	HP M4555MFP	Fuser gear(18T)	1.00
RC1-0497-000	HP M4555MFP	Fuser Latch Clip, right	1.00
RC1-0091-000	HP M4555MFP	Fuser Latch Clip, left	1.00
RL1-1663-000	HP M4555MFP	Pick up roller Tray1	1.00
RL1-1654-000	HP M4555MFP	Pick up roller Tray1	1.00
RL1-1641-000	HP M4555MFP	Pick up roller Tray1	1.00

<b>HP 5000</b>			
RF5-1485	HP 5000	Separation Pad,with spring	2.54
RF5-2400-000	HP 5000	Separation Pad-Tray 1	1.38
RF5-2399-000	HP 5000	Pad assembly	1.46
RF5-3439-000	HP 5000	Separation Pad-Tray 1	1.82
RB2-1984-000	HP 5000	Delivery Roller	3.94
RB2-1821-000	HP 5000	Pick up Roller-Tray 2	1.00
RB2-1820-000	HP 5000	Pick up Roller-Tray 1	1.00
RF5-2634-000	HP 5000	Feed Roller-Tray 2	1.00
RF5-2636-000	HP 5000	Pick up Roller Ass'y	3.18
RF5-2409-000	HP 5000	Arm Swing	2.24
RS6-0348-000	HP 5000	Fuser Gear(29T/14T)	1.00
RB2-1919-000	HP 5000	Fuser Pressure Roller	13.62
RG5-3528-FM3	HP 5000	Fuser Film Sleeve(Japanese material)	3.74
RG5-3527-HEAT	HP 5000	Heating Element(220V)	15.90
RG5-3526-HEAT	HP 5000	Heating Element(110V)	15.90
RG5-3579-000	HP 5000	Transfer Roller	6.32
RS6-1389-000	HP 5000	Bushing, Pressure Roller	1.26
RS6-0356-000	HP 5000	Fuser Gear(21T)	1.00
RS5-0355-000	HP 5000	Fuser Gear(16T/23T)	1.00
RS6-0354-000	HP 5000	Fuser Gear(15T)	1.00
<b>HP 5100</b>			
RG5-3528-FM3	HP 5100	Fuser Film Sleeve(Japanese material)	3.74
RG5-7060-HEAT	HP 5100	Heating Element 110V	15.90
RG5-7061-HEAT	HP 5100	Heating Element 220V	15.90
RB2-1821-000	HP 5100	Pick up Roller Tray2	1.00
RB2-1820-000	HP 5100	Pick up Roller Tray1	1.00

RF5-2636-000	HP 5100	Feed Roller-Tray 2	3.12
RF5-2634-000	HP 5100	Pick up Roller	1.00
RB2-1919-000	HP 5100	Fuser Pressure Roller	13.62
RS5-1389-000	HP 5100	Bushing, Pressure Roller	1.26
RS6-0348-000	HP 5100	Fuser Gear( 29/14 T )	1.00
RS6-0354-000	HP 5100	Fuser Gear( 15T )	1.00
RS6-0355-000	HP 5100	Fuser Gear( 16/23 T )	1.00
RS6-0356-000	HP 5100	Fuser Gear( 21 T )	1.00
RF5-4119-000	HP 5100	Separation Pad-Tray 1	1.82
RF5-2400-000	HP 5100	Separation Pad-Tray 1	1.38
RF5-4128-000	HP 5100	Separation Pad-Tray 2	2.60
RF5-2399-000	HP 5100	Separation Pad	1.46
RF5-2409-000	HP 5100	Arm Swing	2.24
RG9-1542-000	HP 5100	Transfer Roller	6.32
<b>HP 5200</b>			
LPR-5200	HP 5200	Fuser Pressure Roller	16.56
RG5-3528-FM3	HP 5200	Fuser Film Sleeve(Japanese material)	3.74
RU5-0556-000	HP 5200	Fuser gear( 29T )	1.52
RU5-0577-000	HP 5200	GEAR FUSER DRIVE (31T)	1.28
RU5-0576-CLN	HP 5200	GEAR DRIVE (17/36T)	1.48
RU5-0575-CLN	HP 5200	GEAR DRIVE (19/33T)	1.48
N/A	HP 5200	Clutch separation roller(27T/28T)	1.66
N/A	HP 5200	Fuser gear( 16T )	1.00
N/A	HP 5200	GEAR DRIVE (16/18T)	1.00
N/A	HP 5200	Roller,Pick up Cam	1.22
RM1-2485	HP 5200	Transfer Roller	6.44
RC2-0418-000	HP 5200	Separation Pad Tray1	1.00

RM1-1298-pad	HP 5200	pad only, Separation	1.28
RC1-6997-000	HP 5200	Pick up roller	1.00
RM1-3537/0731	HP 5200	Pick up Roller Tray2	2.74
PS-P3005-ASS	HP 5200	The paper rolling of Tray1	1.34
RS5-1389-000	HP 5200	Bushing, Pressure Roller	1.26
<b>HP M5025/5035MFP</b>			
Q7829-67928	HP M5025/5035	Transfer roller	6.30
RL1-0915-000	HP M5025/5035	Pick up roller Tray1	1.00
RM1-3763-000	HP M5025/5035	Pick up roller Tray2	3.00
Q7829-67929	HP M5025/5035	Pick up roller-Tray 2	1.00
LPR-M5035	HP M5025/5035	Fuser pressure roller	16.56
<b>HP M600/M601</b>			
LPR-M601	HP M601/600	Fuser pressure roller	28.00
RM1-4554-FM3	HP M601/600	Fuser Film Sleeve(Japanese material)	38.00
RU7-0296-000	HP M601/600	Fuser gear(32T)	2.00
RM1-5462-000	HP M601/600	Transfer Roller Assy	5.80
DR-M601-00	HP M601/600	Delivery roller lower	2.82
DR-M600-LO	HP M601/600	Delivery roller lower	8.62
N/A	HP M601/600	Bushing pressure roller	2.20
RM1-0036-000	HP M601/600	Pick up roller Tray2	2.00
RM1-0037-000	HP M601/600	Pick up roller Tray2	2.00
RL1-1663-000	HP M601/600	Pick up roller Tray1	2.00
RL1-1654-000	HP M601/600	Pick up roller Tray1	2.00
RL1-1641-000	HP M601/600	Pick up roller Tray1	2.00
RU7-0297-000	HP M601/600	Fuser gear(18T)	2.00
RU7-0298-000	HP M601/600	Fuser gear(17T)	2.00
RC2-5208-000	HP M601/600	Fuser Guide Delivery	6.30



CVR-P4014-L	HP M601/600	cover Asm Left	5.36
CVR-P4014-R	HP M601/600	cover Asm Right	3.30
RC1-0497-000	HP M601/600	Fuser Latch Clip, right	2.00
RC1-0091-000	HP M601/600	Fuser Latch Clip, left	2.00
N/A	HP M601/600	Heating Element 110V	21.40
N/A	HP M601/600	Heating Element 220V	21.40
RC1-0387-000	HP M601/600	Guide Upper Delivery	5.26
RC1-0072-000	HP M601/600	Lower Enerance Guide	4.28
<b>Color HP CP1025</b>			
LPR-1025	Color HP CP1025	Fuser pressure roller	7.72
RL1-1442	Color HP CP1025	Pickup Roller	0.50
<b>Color HP CP1215</b>			
LPR-1215	Color HP CP1215	Fuser pressure roller	7.36
N/A	Color HP CP1215	Bushing, pressure roller	2.00
RU6-0112	Color HP CP1215	Fuser gear	2.00
<b>Color HP 1600</b>			
RM1-1821-FM3	Color HP 1600	Fuser Film Sleeve	10.28
RC1-5440-000	Color 1600/1020/1022	Pick up Roller	1.00
RC1-3515-000	Color 1600/1160/2420	Separation Pad	1.28
LPR-2600	Color HP 1600	Fuser Pressure Roller	7.36
<b>Color Laser Jet CP2020/2025/2055</b>			
LPR-2020	Color CP2020/2025/2055	Lower Sleeved Roller	7.08
<b>Color HP 2500</b>			
RB3-0191-000	Color HP 2500	Lower Sleeved Roller	7.70
RB3-0160-000	Color HP 2500	Paper Pick up Tray1	1.00
RF5-4012-000	Color HP 2500	Separation Pad Tray1	1.62
RC1-0954-000	Color HP 2500	Separation Pad Tray2	1.00

RB3-0161-000	Color HP 2500	Pick up Roller Tray2	1.00
<b>Color HP 2550</b>			
RB3-1034-000	Color 2550/3500/3700	Lower Sleeved Roller	7.70
RF5-4012-000	Color HP 2550	Separation Pad Tray1	1.62
RB3-0160-000	Color HP 2550	Paper Pick up Tray1	1.00
<b>Color HP 2600</b>			
RM1-1821-FM3	Color HP 1600	Fuser Film Sleeve	10.28
LPR-2600	Color HP 2600	Fuser Pressure Roller	7.36
<b>Color HP 2840</b>			
RB3-1034-000	Color HP 2820/2840	Lower Sleeved Roller	7.70
RF5-4012-000	Color 2820/2840	Separation Pad Tray1	1.62
RB3-0160-000	Color HP 2820/2840	Paper Pick up Tray1	1.00
<b>COLOR 3500/3700</b>			
RB3-1034-000	3500/3700/2550	Fuser Pressure Roller	7.70
RM1-0740-000	3500/3700/2550	Transfer Roller	6.28
RC1-0939-000	Color 3500/3700	Separation Pad-Tray1	1.00
RC1-0954-000	3500/3700/2300	Separation Pad-Tray2	1.00
RC1-0945/1535	3500/3700/2300	Paper Pick up Roller-Tray1	1.00
RM1-0731-000	Color 3500/3700	Pick up Assy-Tray2	2.74
DR-3500	Color 3500/3700	Delivery Roller	2.44
BRG-3500-LOW	Color 3500/3700	Bearing, pressure roller	3.60
<b>COLOR HP 3600</b>			
LPR-3600	Color HP 3600	Lower Sleeve Roller	9.00
RM1-2709-000	Color HP 3600	Separation pad	1.20
RU5-0184/0183-000	Color HP 3600	Clutch Separation Roller	1.44
N/A	Color HP 3600	FUSER GEAR 15T	1.90
<b>COLOR HP 3820</b>			
N/A	HP 3820	DOCKSTATION Gear Small	1.14

N/A	HP 3820	DOCKSTATION Gear Big	1.44
<b>COLOR HP 4500</b>			
RF5-2111-000	Color HP 4500	Separation Pad	1.00
RB2-0734-000	Color HP 4500	Separation Pad	1.54
RF5-2110-000	Color HP 4500	Feed/Separation	1.00
RF5-3750-000	Color HP 4500	Feed/Separation	1.38
RF5-2490-000	Color HP 4500	Pick up Roller	1.00
RB1-8865-000	Color HP 4500	Paper pick up Roller	1.00
RB1-8957-000	Color HP 4500	Paper pick up Roller	1.00
RB2-0717-000	Color HP 4500	Paper pick up Roller	1.40
RF5-2092-000	Color HP 4500	Paper pick up Roller	1.00
RF5-3739-000	Color HP 4500	Paper pick up Roller	1.00
RF5-2112-000	Color HP 4500	Transfer Roller, W/Gear	4.62
RB2-0501-000	Color HP 4500	Upper fuser Roller	25.06
RB2-0502-000	Color HP 4500	Lower Sleeve Roller	25.06
<b>COLOR HP 4600</b>			
LPR-4600	Color HP 4600	Fuser Pressure Roller	10.32
RG9-1529-000	Color HP 4600	Paper pick up Roller Tary1	1.00
RF5-3739-000	Color HP 4600	Paper pick up Roller Tary2	1.00
RF5-3750-000	Color HP 4600	Separation Pad Tary1	1.38
<b>COLOR HP 4700</b>			
LPR-4700	Color HP 4700	Fuser Pressure Roller	13.22
RF5-3750-000	Color HP 4700	Separation Pad Tary1	1.38
RL1-0019-000	Color HP 4700	Paper pick up Roller-Tray1	1.00
RM1-0036-000	Color HP 4700	Pick up Roller	1.00
RM1-0037-000	Color HP 4700	Pick up Roller	1.00
<b>COLOR HP 5500</b>			

LPR-5500-000	Color HP 5500	Fuser Pressure sollar	17.50
RF5-3338-000	Color 5500/HP9000	Pick up Roller	1.00
RF5-3340-000	Color 5500/HP9000	Pick up Roller	1.00
RF5-3865-000	Color HP 5500	Separation Pad Tray1	1.00
RG9-1529/RG5-3718	Color HP 5500	Pick up Roller Tray1	1.00
RB2-5759-000	Color 5500/HP9000	Torque limiter	3.18
<b>HP 8000/5Si</b>			
RF5-1455-000	HP 8000/5Si	Separation Pad	1.24
RF5-1834-000	HP 8000/5Si	Pick up Roller	1.00
RF5-6730-000	HP 8000/5Si	Pick up Roller	1.00
RF5-1835-000	HP 8000/5Si	Pick up Roller	1.00
RB1-6686-000	HP 8000/5Si	Upper delivery Roller	3.94
RB2-6687-000	HP 8000/5Si	Lower delivery Roller	3.52
RB2-3546-000	HP 8000/5Si	Cleaning Roller	2.44
RB2-3546-kit	HP 8000/5Si	Cleaning Roller kit	3.88
RF5-1412-000	HP 8000/5Si	Transfer Roller, W/Gear	5.40
RB1-6623-000	HP 8000/5Si	Fuser Pressure Roller	16.20
RB1-6622-000	HP 8000/5Si	Upper fuser Roller	8.04
RB1-6606-000	HP 8000/5Si	Roller delivery	4.64
RB1-6581-000	HP 8000/5Si	Roller second pass	5.40
RS5-0750-000	HP 8000/5Si	Fuser Gear	1.00
RS5-0748-000	HP 8000/5Si	Fuser Gear(20T)	1.00
RS5-0749-000	HP 8000/5Si	Fuser Gear(29T)	1.00
RS5-0751-000	HP 8000/5Si	Fuser Gear(18T)	1.00
RS5-0752-000	HP 8000/5Si	Fuser Gear(14T)	1.00
RB1-6561-000	HP 8000/5Si	Paper feed Roller	1.24
RB1-6598-000	HP 8000/5Si	Paper feed Roller,upper	1.24

RB1-6823-BSH	HP 8000/5Si	Bushing,heating Roller	1.64
RB1-6647-000	HP 8000/5Si	bushing, Cleaning Roller	1.00
RB1-6588-000	HP 8000/5Si	Torque Limiter	3.46
RB1-6614-000	HP 8000/5Si	Fuser Flag	1.14
XG9-0266-000	HP 8000/5Si	Bearing, Fuser Roller	3.80
XG9-0331-000	HP 8000/5Si	Bearing, Lower Roller	3.16
<b>HP 8100</b>			
RF5-2703-000	HP 8100	Separation Pad	1.20
RF5-1834-000	HP 8100	Pick up Roller	1.00
RF5-2708-000	HP 8100	Pick up Roller	1.00
RF5-1835-000	HP 8100	Pick up Roller	1.00
RB1-9526-000	HP 8100	Pick up Roller-mp tray	1.00
RG9-1361-000	HP 8100	Transfer Roller	5.72
RB2-3521-000	HP 8100	Upper fuser Roller	8.04
RB2-3518 -000	HP 8100	Fuser Gear(3T)	1.00
RS6-0505-000	HP 8100	Fuser Gear(26T)	1.14
RS6-0507-000	HP 8100	Fuser Gear(54T)	1.40
RS5-0748-000	HP 8100	Fuser Gear(20T)	1.00
RS5-0752-000	HP 8100	Fuser Gear(14T)	1.00
RB2-3522-000	HP 8100	Fuser Pressure Roller	17.80
RB1-6610-000	HP 8100	Bushing, Upper Fuser Roller	1.64
XG9-0377-000	HP 8100	Bearing Upper Fuser Roller	3.80
XG9-0379-000	HP 8100	Bearing, Lower Roller	3.16
RB1-6588-000	HP 8100	Torque limiter	3.46
RB1-6614-000	HP 8100	Fuser Flag	1.14
RB1-6606-000	HP 8100	Roller Delivery	4.74
RB1-6581-000	HP 8100	Roller second pass	5.40

RB1-6561-000	HP 8100	Paper feed Roller	1.24
RB1-6598-000	HP 8100	Paper feed Roller	1.24
RB1-6686-000	HP 8100	Delivery Roller	3.94
RB1-6687-000	HP 8100	Roller Feed	3.60
RB2-3516-000	HP 8100	Cleaning Roller	2.44
RB2-3517-000	HP 8100	Cleaning Roller Bushing	1.00
Rb2-3516-KIT	HP 8100	Cleaning Roller Assembly	3.88
<b>HP 8500</b>			
RB1-9526-000	HP 8500	Feed Pickup Roller	1.00
RF5-1834-000	HP 8500	Paper Pickup Roller	1.00
RF5-1835-000	HP 8500	Paper Pickup Roller	1.00
RF5-2708-000	HP 8500	Paper Pickup Roller	1.00
RF5-1989-000	HP 8500	Separation Pad	1.46
RB1-9720-000	HP 8500	Fuser Pressure Roller	23.16
<b>HP 9000</b>			
RF5-3319-000	HP 9000	Transfer Roller, W/Gear	5.68
RF5-3340-000	HP 9000	Pick up Roller	1.00
RF5-3338-000	HP 9000	Pick up Roller	1.00
RF5-3403-000	HP 9000	Pick up roller tray	1.18
RF5-3404-000	HP 9000	Pick up roller tray	1.38
RB2-5759-000	HP 9000	Torque Limiter, Spacer	3.18
RS6-0844-000	HP 9000	Fuser Gear(18T)	1.00
RS6-0845-000	HP 9000	Fuser Gear(21T)	1.00
RS6-0841-000	HP 9000	Fuser Gear(49T)	1.32
RS6-0842-000	HP 9000	Fuser Gear(36T/24T)	1.32
RB2-5759-000	HP 9000	Troque Limiter	3.18
DR-9000-LOW	HP 9000	lower Delivery Roller	3.90

BSH-9000-UP	HP 9000	Bushing,Upper Fuser Roller	2.30
BSH-9000-LOW	HP 9000	Bushing,Pressure Roller	1.98
RB2-5921-000	HP 9000	Fuser Pressure Roller	23.44
<b>HP 9500</b>			
RF5-3340-000	Color HP 9500	Pick up Roller	1.00
RF5-3338-000	Color HP 9500	Pick up Roller	1.00
RB2-1820-000	Color HP 9500	Pick up Roller Tray1	1.00
<b>HP 4/4+/EX/4M</b>			
RF5-0343-000	HP 4+/EX/4M	Separation Pad	1.20
RB1-2650-000	HP 4+/5/5M	Mp tray pick up Roller	1.00
RB1-2127-000	HP 4+/EX/4M	Mp tray pick up Roller	1.00
RB1-3477-000	HP 4+/EX/4M	pick up Roller tray2	1.00
RB1-2632-000	HP 4+/EX/4M	Lower pick up Roller	1.00
RB1-2126-000	HP 4+/EX/4M	Pick up Roller	1.00
RS5-0388-000	HP 4+/5	Fuser Gear(42T)	1.00
RS5-0231-000	HP 4	Fuser Gear(19T)	2.44
RF5-0349-000	HP 4+/EX/4M	Transfer Roller	4.98
RB1-2263-000	Laser jet 4	Upper fuser roller	7.12
RB1-2264-000	Laser jet 4	Fuser Pressure Roller	8.44
RB1-3516-000	HP 4+/EX	Upper fuser Roller	6.74
RS5-1097-000	HP 4+/EXII	Bushing Right, Upper Fuser Roller	1.06
RS5-1098-000	HP 4+/EXII	Bushing Left, Upper Fuser Roller	1.06
RS5-0230-000	HP 4+/EX/4M	Fuser Gear(34T)	1.00
RS5-0232-000	HP 4+/EX/4M	Fuser Gear(23T)	1.00
RB1-3517-000	HP 4+/EX/4M	Fuser Pressure Roller	9.14
RF5-1076-000	HP 4/EX/4M	Upper delivey Roller	2.54
RF5-1077-000	HP 4+/EX/4M	Lower delivery Roller	2.16

RF5-0350-000	HP 4+/EX/4M	Arm Swing	1.70
<b>HP 4L/4P/4ML/PX</b>			
RB1-3029-000	4L/4P/4ML/PX	Pick up Roller	1.00
RB1-3368-000	4L/4P/4ML/PX	Pick up Roller	1.00
RB1-3103-000	4L/4P/4ML/PX	Delivery Roller	2.54
RG5-0676-FM3	4L/4P/4ML/PX	Fuser Film Sleeve(Japanese material)	3.60
RB1-0596-000	4L/4P/4ML/PX	Transfer Roller	4.62
RB1-3100-000	4L/4P/4ML/PX	Fuser Pressure Roller	7.04
RB1-3107-000	4L/4P/4ML/PX	Roller holder	1.00
RG5-0765-Gear	4L/4P/4ML/PX	Motor Gear(18T)	1.06
<b>HP 4VC/BX</b>			
RF5-0302-000	HP 4VC/BX	Separation Pad	1.40
RB1-1411-000	HP 4VC/BX	Pick up Roller,mp tray1	1.00
RB1-1386-000	HP 4VC/BX	pick up Roller tray2	1.00
RG5-1410-000	HP 4VC/BX	Transfer Roller	5.82
RB1-5495-000	HP 4VC/BX	Upper fuser Roller	7.40
RS5-0603-000	HP 4VC/BX	Fuser Gear(39T)	1.00
RS5-0183-000	HP 4VC/BX	Gear(14T)	1.00
RS5-0184-000	HP 4VC/BX	Gear(18T)	1.00
RS5-0180-000	HP 4VC/BX	Fuser Gear(32T)	1.00
RS5-0194-000	HP 4VC/BX	Fuser Gear(18T)	1.00
RB1-1443-000	HP 4VC/BX	Fuser Pressure Roller	13.62
RG5-0198-000	HP 4VC/BX	Face-down delivery Roller	3.80
RS5-0182-000	HP 4VC/BX	Gear(14T)	1.00
<b>HP 3SI/4SI/NX</b>			
RF5-0081-000	HP 3SI/4SI/NX	Duplex pick up Roller	1.00
RF5-0041-000	HP 3SI/4SI/NX	Pick up Roller	1.00



RG5-0141-000	HP 3SI/4SI/NX	Transfer Roller	5.40
RB1-0323-000	HP 3SI/4SI/NX	Upper fuser Roller	7.06
RS5-0062-000	HP 3SI/4SI/NX	Fuser Gear(33T)	1.20
RF5-0060-000	HP 3SI/4SI/NX	Fuser Gear(16T)	1.00
RS5-0057-000	HP 3SI/4SI/NX	Fuser Gear(23T)	3.80
RS5-0059-000	HP 3SI/4SI/NX	Fuser Gear(18T)	3.80
RF5-0068-000	HP 3SI/4SI/NX	Fuser Gear(27T)	3.12
RB1-0818-000	HP 3SI/4SI/NX	Clip,Transfer Roller	1.00
RB1-0531-000	HP 3SI/4SI/NX	Delivery Roller	2.08
<b>HP 5p/6p</b>			
RF5-0343-000	HP 5p/6p	Separation Pad	1.20
RB1-6332-000	HP 5p/6p	Pick up Roller	1.00
RB1-2205-000	HP 5p/6p	Pick up Roller	1.00
RG5-0683-000	HP 5p/6p	Delivery Roller	2.36
RB1-9181-000	HP 5p/6p	Exit Roller	1.98
RG5-1700-FM3	HP 5p/6p	Fuser Film Sleeve(Japanese material)	3.60
RG5-2801-HEAT	HP 5p/6p	Heating Element(220V)	13.92
RG5-2800-HEAT	HP 5p/6p	Heating Element(110V)	13.92
RG5-1290-000	HP 5p/6p	Transfer Roller	4.74
RS5-0637-000	HP 5p/6p	Fuser Gear,Pressure Roller(24T)	1.00
RS5-0979-000	HP 6p	Fuser Gear((17T/16T))	1.00
RS5-0978-000	HP 5p	Fuser Gear((17T/17T))	1.00
RB1-9210-000	HP 5p/6p	Fuser Pressure Roller(6P)	6.70
RB1-5910-000	HP 5p/6p	Fuser Pressure Roller(5P)	6.70
RB1-3107-000	HP 5p/6p	Roller holder	1.00
RS5-0636-000	HP 5p/6p	Fuser Gear(16T)	1.00
<b>HP 5L/6L</b>			

RB1-7181-000	HP 5L/6L	Separation Pad(2pc/set)	2.00
RY7-5077-000	HP 5L/6L	Separation Pad kit	1.62
RS5-2502-000	HP 5L/6L	Spring, Separation arm	1.00
RB2-1634-000	HP 5L/6L	Pick up Roller	1.00
RB2-1699-000	HP 5L/6L	Feed up Roller	1.00
RG5-1951-000	HP 5L/6L	Pick up Roller ass'y	5.74
RF5-2367-000	HP 5L/6L	Delivery Roller	2.16
RF5-1521-000	HP 5L/6L	Delivery Roller	2.16
RF5-1516-000	HP 5L	Fuser Pressure Roller	6.70
RF5-2364-000	HP 6L	Fuser Pressure Roller	6.70
RG5-1964-FM3	HP 5L/6L	Fuser Film Sleeve(Japanese material)	3.60
RG5-1965-HEAT	HP 5L/6L	Heating Element(220V)	8.72
RG5-1964-HEAT	HP 5L/6L	Heating Element(110V)	8.72
RF5-1534-000	HP 5L/6L	Transfer Roller	4.80
RB1-7246-000	HP 5L/6L	Bushing, Pressure Roller	1.00
RB2-7180-Gear	HP 5L/6L	Arm ass'y(exit Roller)	1.14
RB1-7203-000	HP 5L/6L	Arm Pressure,Feed Roller	1.00
RH7-1320-000	HP 5L/6L	Motor Gear	1.30
<b>SAMSUNG ML1510</b>			
JC72-01231A	ML1510	Pick up Roller	2.00
JC66-00600A	ML1510	Fuser Pressure Roller	7.70
JC66-00601A	ML1510	Upper fuser Roller	6.06
CGA-SM1510	ML1510	Coupling Gear Assembly	1.64
SP-SM1510	ML1510	Separation Pad	1.98
BSH-SM1510 upR	ML1510	Bushing, heat Roller	2.00
JC66-00564A	ML1510	Fuser Gear 37T	2.00
JC66-00388A	ML1510	Motor Gear 53 /26T	2.00

<b>SAMSUNG ML1610</b>			
PUR-SM1610	ML1610/2240	Pick up Roller	2.00
JC66-00600A	ML1610/2240	Fuser Pressure Roller	7.70
JC66-00601A	ML1610	Upper fuser Roller	6.06
JC61-01169A	ML1610	Separation Pad	1.16
TNR-SM1610	ML1610	Transfer Roller	4.62
CGA-SM1610	ML1610	Coupling Gear Assembly	1.64
DR-SM1610	ML1610	Delivery Roller	2.16
BSH-SM1510 upR	ML1610	Bushing, heat Roller	2.00
JC66-00564A	ML1610	Fuser Gear	2.00
<b>SAMSUNG ML1675/1670/1676/1660</b>			
N/A	ML1675/1670/1676/1660	Fuser pressure roller	8.06
JC66-00601A	ML1675/1670/1676/1660	Upper fuser roller	6.06
RC2-3425/1048	ML1675/1670/1676/1660	Pick up roller	2.00
JC66-00564A	ML1675/1670/1676/1660	Fuser gear 37T	2.00
<b>SAMSUNG ML1710/1740</b>			
JC72-01231A	ML1710/1740	Pick up Roller	2.00
JC66-00600A	ML1710/1740	Fuser Pressure Roller	7.70
JC66-00601A	ML1710/1740	Upper fuser Roller	6.06
CGA-SM1510	ML1710/1740	Coupling Gear Assembly	1.64
SP-SM1510	ML1710/1740	Separation Pad	1.98
BSH-SM1510 upR	ML1710/1740	Bushing, heat Roller	1.34
JC66-00564A	ML1710/1740	Fuser Gear 37T	2.00
JC66-00388A	ML1710/1740	Electric Motor Gear 53 /26T	1.70
<b>SAMSUNG ML-1910/1911</b>			
JC66-01256B	ML-1910/1911	Upper Fuser Roller	6.76
JC66-01663A	ML-1910/1911	Fuser Pressure Roller	7.42

JC71-03514A	ML-1910/1911	Pick Up Roller	1.92
JC97-01931A	ML-1910/1911	Separation pad	1.92
<b>SAMSUNG ML-2010</b>			
JC66-00600A	ML-2010	Fuser pressure roller	7.70
JC66-00601A	ML-2010	Upper fuser roller	6.06
BSH-SM1510-UPR	ML-2010	Bushing, heat roller	1.36
JC66-00564A	ML-2010	Fuser gear 37T	1.16
<b>SAMSUNG ML-2161/3401</b>			
N/A	ML-2161/3401	Fuser pressure roller	7.70
N/A	ML-2161/3401	Upper fuser roller	6.06
<b>SAMSUNG ML-2240</b>			
JC66-00600B	ML2240	Fuser Pressure Roller	7.70
JC66-01972B	ML2240	Upper Fuser Roller	6.06
JC61-01173A	ML2240	Pick Up Roller	2.00
BSH-SM2240-UPR	ML2240	Bushing, Heat Roller	1.36
JC66 – 00564A	ML2240	Fuser Gear	1.16
<b>SAMSUNG ML-2250</b>			
JC97-02034A	ML-2250	Pickup Roller Tray2	1.28
JC97-01926A	ML-2250	Pickup Roller Tray1	1.52
JC66-00729A	ML-2250	Upper fuser Roller	7.04
JC66-00600A	ML-2250	Fuser Pressure Roller	7.70
SP-SM1510	ML-2250	Separation Pad	2.00
<b>SAMSUNG ML-2510</b>			
JC66-01254A	ML-2510	Upper Fuser Roller Gear	2.00
JC73-00239A	ML-2510	Pick up roller	2.00
JC66-01256A	ML-2510	Upper fuser roller	7.04
JC66-00600A	ML-2510	Fuser pressure roller	7.70

<b>SAMSUNG ML-2550</b>			
N/A	ML-2550	Upper fuser roller	7.04
N/A	ML-2550	Fuser pressure roller	9.00
<b>SAMSUNG ML-2850/2851</b>			
JC66-01254A	ML-2850/2851	Upper Fuser Roller Gear	2.00
JC97-02034A	ML-2850/2851	Pickup Roller TRAY2	2.00
JC97-01926A	ML-2850/2851	Pick up poller tray1	2.00
JC97-01931A	ML-2850/2851	Separation pad	2.00
JC66-01256B	ML-2850/2851	Upper fuser roller	6.76
JC66-01663A	ML-2850/2851	Fuser pressure roller	7.42
<b>SAMSUNG ML-3310</b>			
N/A	ML-3310	Fuser pressure roller	7.70
<b>SAMSUNG ML-3050/Xerox 3428</b>			
N/A	ML-3050/Xerox 3428	Upper fuser roller	8.68
N/A	ML-3050/Xerox 3428	Bushing, heat roller	2.50
N/A	ML-3050/Xerox 3428	Fuser pressure roller	11.30
JC97-01926A	ML-3050/Xerox 3428	Pick up poller tray1	2.00
SP-SM1510	ML-3050/Xerox 3428	Separation pad tray2	2.00
<b>SAMSUNG ML-3470/ML-3471/SCX 5530</b>			
JC66-01593A	SAMSUNG ML-3470/ML-3471	Upper fuser roller	8.70
JC66-01453A	SAMSUNG ML-3470/ML-3471	Fuser pressure roller	7.70
JC97-02034A	SAMSUNG ML-3470/ML-3471	Pickup Roller TRAY2	2.00
<b>SAMSUNG SCX-4100</b>			
JC72-01231A	SCX-4100	Pick up Roller	2.00
LPR-SM1210	SCX-4100	Fuser Pressure Roller	7.04
JC66-00601A	SCX-4100	Upper fuser Roller	6.06
SP-SM1510	SCX-4100	Separation Pad	2.00

JC66-00564A	SCX-4100	Fuser Gear,heat Roller37T	2.00
BSH-SM1510	SCX-4100	Bushing, heat Roller	2.00
<b>SAMSUNG SCX-4200</b>			
JC72-01231A	SCX-4200	Pick up Roller	2.00
JC66-00600A	SCX-4200	Fuser Pressure Roller	7.70
JC66-00601A	SCX-4200	Upper fuser Roller	6.06
SP-SM1510	SCX-4200	Separation Pad	2.00
CGA-SM1510	SCX-4200	Coupling Gear Assembly	2.00
JC66-00564A	SCX-4200	Fuser Gear,heat Roller37T	2.00
BSH-SM1510	SCX-4200	Bushing, heat Roller	2.00
<b>SAMSUNG SCX-4216</b>			
JC72-01231A	SCX-4216/XEROX3116	Pick up roller	2.00
JC66-00600A	SCX-4216	Fuser pressure roller	7.70
JC66-00601A	SCX-4200/XEROX3117	Upper fuser roller	6.06
SP-SM1510	SCX-4216/XEROX3116	Separation pad	2.00
CGA-SM1510	SCX-4216	Coupling Gear Assemldy	2.00
JC66-00564A	SCX-4216	Fuser gear,heat roller37T	2.00
BSH-SM1510	SCX-4216	Bushing, heat roller	2.00
JC66-00388A	SCX-4216/XEROX3116	Motor Gear 53 /26T	2.00
<b>SAMSUNG ML4500</b>			
JC66-01254A	ML4500	Upper Fuser Roller Gear	2.00
JC72-00124A	ML4500/ML1210	Separation Pad	2.34
JC73-00018A	ML4500/ML1210	Pick up Roller	2.00
JC71-00012B	ML4500/ML1210	Upper fuser Roller	5.74
LPR-4500	ML4500/ML1210	Fuser Pressure Roller	7.04
DP-SM4500	ML4500/ML1210	Delivery Roller	2.00
FG-SM4500	ML4500/ML1210	Fuser Gear	2.00

BSH-SM4500 upR	ML4500/ML1210	Bushing, Heat Roller	2.00
CGA-SM4500	ML4500/ML1210	Coupling Gear Assembly	2.00
<b>SCX-4521F</b>			
PUR-SM4521	SCX-4521F	Pickup Roller	2.00
JC66-00600A	SCX-4521F	FUSER PRESSURE ROLLER	7.70
JC66-00601A	SCX-4521F	UPPER FUSER ROLLER	6.06
JC61-01169A	SCX-4521F	SEPARATION PAD	2.00
JC66-00807A	SCX-4521F	Fuser Gear 35T/63T	2.00
TNR-SM4521	SCX-4521F	TRANSFER ROLLER	4.98
JC97-02179A	SCX-4521F	COUPLING GEAR ASSEMBLY	2.00
DR-SM4521F	SCX-4521F	DELIVERY ROLLER	2.20
BSH-SM4521-UPR	SCX-4521F	BUSHING, HEAR ROLLER	2.00
JC66-00564A	SCX-4521F	FUSER GEAR	2.00
<b>SAMSUNG 4550/4050</b>			
JC66-00931A	ML4550/4050	Fuser pressure roller	15.52
<b>SCX-4725FN/ML2571N</b>			
JC66-01256A	SCX-4725FN/2571	Upper fuser roller	7.04
JC66-00600A	SCX-4725FN	Fuser pressure roller	7.70
JC66-01254A	SCX-4725FN/2571	Fuser gear, heat roller 45T	2.00
JC73-00239A	SCX-4725FN/2571	Pick up roller	2.00
<b>SCX4824/4828FN</b>			
JC66-01256B	SCX4824/4828FN	Upper Fuser Roller	6.76
JC66-01663A	SCX4824/4828FN	Fuser Pressure Roller	7.42
JC66-01254A	SCX4824/4828FN	Fuser gear, heat roller 45T	2.00
JC66-00725A	SCX4824/4828FN	Transfer roller	4.64
JC97-03062A	SCX4824/4828FN	Pick up roller	2.00
JC97-01931A	SCX4824/4828FN	Separation pad	2.00

<b>SAMSUNG 5100</b>			
JC71-00004A	SAMSUNG 5100	Upper fuser Roller	5.74
JC75-00027A	SAMSUNG 5100	Fuser Pressure Roller	6.68
<b>SAMSUNG CLP-300</b>			
JC61-01466A	SAMSUNG CLP-300	Transfer roller	5.26
JC66-01079A	SAMSUNG CLP-300	Fuser Pressure Roller	7.12
<b>SAMSUNG CLP-315</b>			
JC73-00239A	SAMSUNG CLP-315	Pick up roller Tire	2.00
JC73-00239A	SAMSUNG CLP-315	Pick up roller	2.00
JC61-01466A	SAMSUNG CLP-315	Transfer roller	5.26
JC66-01780A	SAMSUNG CLP-315	Fuser Pressure Roller	7.12
<b>SAMSUNG SF-565P</b>			
JC66-00601A	SF-565P	Upper fuser Roller	6.06
LPR-1510	SF-565P	Fuser Pressure Roller	7.70
JC66-00564A	SF-565P	Fuser Gear	2.00
CGA-1510	SF-565P	Coupling Gear Assembly	2.00
BSH-1510	SF-565P	Bushing, Heat Roller	2.00
JC72-01231A	SF-565P	Pick up Roller	2.00
SP-1510	SF-565P	Separation Pad	2.08
TRG-1510	SF-565P	Electric Motor Gear 53/26T	2.00
<b>EPSON COLOR LASER C1100</b>			
FTS-C1100-000	Color Laser C1100	Fuser Film Sleeve(Japanese material)	17.12
<b>EPSON 2020/XEORX 255/305/302</b>			
N/A	EPSON 2020/XEORX 255/305/302	Upper fuser roller	9.20
N/A	EPSON 2020/XEORX 255/305/302	Fuser pressure roller	17.12
<b>EPSON 1300W/1350W</b>			



4136-5501-01	1300W/1350W	Upper fuser Roller	7.36
4136-5502-01	1300W/1350W	Fuser Pressure Roller	9.00
<b>EPSON EPL 5700/5800</b>			
1040806	EPL 5700/5800	Upper fuser Roller	6.06
1040805	EPL 5700/5800	Fuser Pressure Roller	8.04
<b>EPSON EPL 6200</b>			
4316-5501-01	EPL 6200	Upper fuser Roller	7.36
4136-5502-01	EPL6200	Fuser Pressure Roller	9.00
<b>Lexmark E120</b>			
UFR-E120	Lexmark E120	Upper Fuser Roller	7.40
LPR-120	Lexmark E120	Fuser Pressure Roller	7.04
TR-E120	Lexmark E120	Transfer Roller	5.74
<b>Lexmark E210/4510</b>			
12G6779	E210/4510	Separation Pad	2.30
12G6780	E210/4510	Clutch Separation	2.00
56P2501	E210/4510	Pick up Roller	2.00
69G9977	E210/4510	Upper Fuser Roller	7.40
69G9978	E210/4510	Lower Pressure Roller	7.04
BSH—E210	E210/4510	Bushing, Hear Roller	2.00
FG-4500	E210/4510	Fuser Gear	2.00
<b>LEXMARK X215</b>			
JC66-00600A	LEXMARK X215	Fuser pressure roller	7.70
JC66-00601A	LEXMARK X215	Upper fuser roller	6.06
SP-SM1510	LEXMARK X215	Separation pad	2.00
CGA-SM1510	LEXMARK X215	Coupling Gear Assemldy	2.00
JC66-00564A	LEXMARK X215	Fuser gear,heat roller37T	2.00
FG-SM1510	LEXMARK X215	Electic Motor Gear 53 /26T	2.00

BSH-SM1510	LEXMARK X215	Bushing, heat roller	2.00
<b>Lexmark E232/230</b>			
UFR-E232	E232/230/234/240/330/332	Upper fuser Roller	7.06
LPR-E232	E232/230/234/240/330/332	Fuser Pressure Roller	8.04
56P1823	E232/230/234/240/330/332	Transfer Roller	5.64
56P1820	E232/230/234/240/330/332	Pick up Roller	2.00
<b>Lexmark E250D/260</b>			
56P1820	E250D	Pick up Roller	2.00
E-250D Film	E250D/260	Fuser Film Sleeve(Japanese material)	16.00
LPR-E250	E250D	Fuser Pressure Roller	10.00
LPR-E260	E260D	Fuser Pressure Roller	10.00
<b>Lexmark E322/320</b>			
12G4483	E322/320	Pick up Roller	3.40
12G4470	E322/320/220	Transfer Roller	4.98
12G4491	E322/320/220	Upper fuser Roller	7.06
12G4494	E322/320/220	Fuser Pressure Roller	8.04
12G0119	E322/320/220	Separation Pad Right	2.00
12G1932	E322/320/220	Separation Pad Left	2.00
N/A	E322/320/220	Pick up Roller Ass'y	4.62
99A1017	E322/320/220	Charge Roller	7.50
12G4493	E322/320/220	Delivery Roller	2.44
<b>Lexmark E312/310/4044</b>			
12G0079	E312/310/4044	Upper fuser Roller	7.70
12G0086	E312/310/4044	Lower Sleeved Roller	8.04
12G0048	E312/310/4044	Transfer Roller	5.64
12G0062	E312/310/4044	Separation Pad	2.00
12G0119	E312/310/4044	Separation Pad Left	2.00

12G0120	E312/310/4044	Separation Pad Right	2.00
12G0067	E312/310/4044	Pick up Roller Ass'y	5.72
12G0070	E312/310/4044	Input paper feed	3.18
12G0084	E312/310/4044	Delivery Roller	2.08
12G0165	E312/310/4044	Delivery Roller	2.44
<b>Lexmark OPTRA M41X/4045</b>			
12G0323	OPERA M41X4045	Pick up Roller	2.00
12G0354	OPERA M41X4045	Transfer Roller	5.72
12G0332	OPERA M41X4045	Fuser Gear 51T	2.00
12G0070	OPERA M41X4045	Input paper feed	3.18
12G0307	OPERA M41X4045	Delivery Roller	3.94
12G0308	OPERA M41X4045	Delivery Roller	3.94
<b>Lexmark 4039</b>			
1381008	Lexmark 4039	Transfer Roller	5.72
1328124	Lexmark 4039	Fuser Gear 38T	2.00
N/A	Lexmark 4039	Bearing, Heat Roller	3.16
69G5480	Lexmark 4039	Pick up Roller	2.00
56P1463	Lexmark 4039	Fuser Gear	2.00
40355101	Lexmark 4039	Flag pack	2.00
<b>Lexmark 4059</b>			
N/A	Lexmark 4059	Fuser Pressure Roller	9.24
99A0070	Lexmark 4059	Paper pick up Roller	2.00
99A0076	Lexmark 4059	Feed pick up Roller	2.00
99A0083	Lexmark 4059	Feed Separation Pad	2.00
99A0159	Lexmark 4059	Bushing, Lower Roller	2.00
99A0150	Lexmark 4059	Bushing, Upper Fuser Roller	2.00
99A0179	Lexmark 4059	Transfer Roller	4.98

99A0336	Lexmark 4059	Delivery Roller	3.40
99A1631	Lexmark 4059	Delivery Roller	3.40
99A0562	Lexmark 4059	Upper fuser Roller	7.06
99A0563	Lexmark 4059	Fuser Gear	2.00
<b>Lexmark OPTERA T420</b>			
UFR-420	OPTERA T420	Upper fuser Roller	7.70
LPR-420	OPTERA T420	Fuser Pressure Roller	8.04
56P0643	OPTERA T420	Transfer Roller, W/Gear	5.72
56P0643	OPTERA T420	Transfer Roller	5.28
<b>Lexmark OPTERA T430</b>			
56P2330-FM3	OPTERA T430	Fuser Film Sleeve(Japanese material)	11.56
LPR-430	OPTERA T430	Fuser Pressure Roller	14.10
56P2329	OPTERA T430	Transfer Roller, W/Gear	5.72
<b>Lexmark OPTERA T520/522</b>			
99A2036	OPTERA T520/522	Upper fuser Roller	7.70
99A2038	OPTERA T520/522	Fuser Pressure Roller	7.70
99A0147	OPTERA T520/522	Delivery Roller	3.94
99A0150	OPTERA T520/522	Bushing, heat Roller	2.00
99A0076	OPTERA T520/522	Pick up Roller,mp tray	2.00
99A0070	OPTERA T520/522	Pick up Roller	2.00
99A0083	OPTERA T520/522	Separation Pad Right	2.00
99A0833	OPTERA T520/522	Guide Only Delivery	4.30
99A1015	OPTERA T520/522	Transfer Roller, W/Gear	4.98
99A0143	OPTERA T520/522	Bearing, Heat Roller	3.16
99A1621	OPTERA T520/522	Bearing, Sleeved Roller	2.16
99A0148	OPTERA T520/522	Fuser Gear	2.00
99A0157	OPTERA T520/522	Fuser Gear	2.00

99A1017	OPTERA T520/522	Charge Roller	7.50
N/A	OPTERA T520/522	DOCTOR Bar	3.58
<b>Lexmark T614/616</b>			
99A0083	T614	Separation Pad	2.00
99A0070	T614/610/612/616	Pick up Roller	2.00
99A0076	T614/610/612/616	Pick up Roller,mp tray	2.00
99A0160	T614/616	Fuser Pressure Roller	7.70
99A1512/1549	T614/616	Upper fuser Roller	7.70
99A0147	T614/610/612/616	Delivery Roller	3.94
99A0157	T614/610/612/616	Fuser Gear	2.00
99A0148	T614/610/612/616	Fuser Gear	2.00
99A0159	T614	Bushing, Sleeve Roller	2.00
99A1015	T614/610/612/616	Transfer Roller	4.98
99A0143	T614/610/612/616	Bearing, Heat Roller	3.16
99A1621	T610/612/616/T614	Bearing, Sleeved Roller	2.16
99A0833	T614/616/610/612	Guide Only Delivery	4.30
N/A	T610/612/616/T614	Doctor bar	3.58
DR-T614	T614/610/612/616	Delivery Roller (4Qty)	17.12
99A2472	T614/610/612/616	Lower Picker Finger	2.00
99A0150	T614/610/612/616	Bushing, Upper Roller	2.00
99A1017	T614/610/612/616	Charge Roller	7.50
<b>Lexmark T620/622</b>			
99A1015	T620/622	Transfer roller	4.98
99A1017	T620/622	Charge Roller	7.50
99A0070	T620/622	Pick up roller	2.00
99A0076	T620/622	Pick up roller,mp tray	2.00
99A0147	T620/622	Delivery roller	3.94

99A0157	T620/622	Fuser gear	2.00
99A0148	T620/622	Fuser gear	2.00
99A0833	T620/622	Guide Only Delivery	4.30
99A0143	T620/622	Bearing, Heat roller	3.16
99A1621	T620/622	Bearing, sleeved roller	2.16
99A0150	T620/622	Bushing, Upper roller	2.00
99A1549	T620/622	Upper fuser roller	7.70
99A2038	T620/622	Fuser pressure roller	7.70
<b>Lexmark T630</b>			
99A0070	Lexmark T630	Pick up Roller	2.00
99A0076	Lexmark T630	Pick up Roller, Mp tray	2.00
99A0158	Lexmark T630	Fuser Pressure Roller	8.68
99A2036	Lexmark T630	Upper fuser Roller	7.70
99A0147	Lexmark T630	Delivery Roller	3.94
DR-T614	Lexmark T630	Delivery Roller (4Qty)	17.12
99A0157	Lexmark T630	Fuser Gear	2.00
99A0148	Lexmark T630	Fuser Gear	2.00
99A0150	Lexmark T630	Bushing heat Roller	2.00
56P1357	Lexmark T630	Transfer Roller	4.98
99A0143	Lexmark T630	Bearing, Heat Roller	3.16
99A1621	Lexmark T630	Bearing, Sleeved Roller	2.16
99A0833	Lexmark T630	Guide Only Delivery	4.30
N/A	Lexmark T630	Doctor bar	3.58
99A2472	Lexmark T630	Lower Picker Finger	2.00
99A1017	Lexmark T630	Charge Roller	7.50
<b>Lexmark T640/642/644</b>			
99A0158	Lexmark T640/642/644	Fuser pressure roller	8.68

40X0130	Lexmark T640/642/644	Transfer roller	4.98
99A0076	Lexmark T640/642/644	Pick up roller,Mp tray	2.00
99A2036	Lexmark T640/642/644	Upper fuser roller	7.70
99A0070	Lexmark T640/642/644	Pick up roller	2.00
99A0143	Lexmark T640/642/644	Bearing, Heat roller	3.16
99A1621	Lexmark T640/642/644	Bearing, sleeved roller	2.16
40X0127	Lexmark T640/642/644	Charge Roller	11.64
99A0150	Lexmark T640/642/644	Bushing, Upper roller	2.00
99A2035	Lexmark T640/642/644	Guide Only Delivery	4.40
99A2469	Lexmark T640/642/644	Delivery roller	3.58
99A0148	Lexmark T640/642/644	Fuser gear	2.00
<b>Lexmark Optra T650/652/654</b>			
99A2036	Optra T650/652/654	Upper Fuser Roller	7.70
99A0158	Optra T650/652/654	Fuser Pressure Roller	8.68
99A0143	Optra T650/652/654	Bearing, Heat Roller	3.16
99A1621	Optra T650/652/654	Bearing, Sleeved Roller	2.16
99A0150	Optra T650/652/654	Bushing, Upper Roller	2.00
99A2469	Optra T650/652/654	Delivery Roller	3.58
99A0148	Optra T650/652/654	Fuser Gear	2.00
<b>Lexmark W820/4025</b>			
SP-W820	Lexmark w820	Separation Pad,Mp tray	2.00
600K61600	Lexmark w820	Pick up Roller	2.00
12G4031	Lexmark w820	Feed Roller kit (6 Rollers)	4.62
022k48230/12G4062	Lexmark w820	Transfer Roller W/Gear	5.72
UFP-W820	Lexmark w820	Upper fuser Roller	9.74
LPR-W820	Lexmark w820	Fuser Pressure Roller	16.84
<b>Xerox PE220</b>			

PUR-SM1610	Xerox PE220	Pick up Roller	2.00
JC61-01169A	Xerox PE220	Separation Pad	2.00
JC66-00600A	Xerox PE220	Fuser pressure roller	7.70
JC66-00601A	Xerox PE220	Upper fuser roller	6.06
CGA-SM1610	Xerox PE220	Coupling Gear Assembly	2.00
BSH-SM1510 upR	Xerox PE220	Bushing, heat Roller	2.00
JC66-00564A	Xerox PE220	Fuser Gear	2.00
TNR-SM1610	Xerox PE220	Transfer Roller	4.62
<b>Xerox 203A</b>			
LPR-203A	Xerox 203A	Lower sleeve roller	8.34
UPR-203A	Xerox 203A	Upper Fuser Roller	7.70
<b>Xerox P8E</b>			
DR-P8E	Xerox P8E	Delivery Roller	2.08
12G0079	Xerox P8E	Upper fuser Roller	7.70
12G0086	Xerox P8E	Lower Sleeved Roller	8.04
SP-P8E	Xerox P8E	Separation Pad	2.00
N/A	Xerox P8E	Pick up Roller	2.00
<b>XEROX 3117</b>			
PUR-SM1610	XEROX 3117	Pick up Roller	2.00
LPR-SM1510	XEROX 3117	Fuser Pressure Roller	8.06
JC66-00601A	XEROX 3117	Upper fuser Roller	6.06
JC61-01169A	XEROX 3117	Separation Pad	2.00
TNR-SM1610	XEROX 3117	Transfer Roller	4.62
CGA-SM1610	XEROX 3117	Coupling Gear Assembly	2.00
DR-SM1610	XEROX 3117	Delivery Roller	2.16
BSH-SM1510 upR	XEROX 3117	Bushing, heat Roller	2.00
JC66-00564A	XEROX 3117	Fuser Gear	2.00



<b>XEROX 3115</b>			
SP-1510	XEROX 3115	Separation Pad	2.08
JC66-06601A	XEROX 3115	Upper fuser Roller	6.74
LPR-1510	XEROX 3115	Lower Sleeved Roller	7.70
JC72-01231A	XEROX 3115	Pick up Roller	2.00
JC66-00564A	XEROX 3115	Fuser Gear, Upper Fuser Roller	2.00
BSH-1510	XEROX 3115	Bushing, Upper Fuser Roller	2.00
CGA-1510	XEROX 3115	Coupling Gear Assembly	2.00
FG-1510	XEROX 3115	Electric Motor Gear 53 /26T	2.00
<b>XEROX 3119</b>			
SP-1510	XEROX 3119	Separation Pad	2.08
JC72-01231A	XEROX 3119	Pick up Roller	2.00
LPR-SM1510	XEROX 3119	Fuser Pressure Roller	8.06
JC66-00601A	XEROX 3119	Upper fuser Roller	6.06
BSH-SM1510 upR	XEROX 3119	Bushing, heat Roller	2.00
JC66-00564A	XEROX 3119	Fuser Gear	2.00
<b>XEROX 3210</b>			
JC75-00054A	Xerox 3210	Pick up Roller	2.00
JC72-00124A	Xerox 3210	Separation Pad	2.34
DR-4500	Xerox 3210	Delivery Roller	2.00
JC71-00012B	Xerox 3210	Upper fuser Roller	6.06
LPR-4500	Xerox 3210	Fuser Pressure Roller	7.04
FG-4500	Xerox 3210	Fuser Gear	2.00
BSH-4500	Xerox 3210	Bushing, Sleeve Roller	2.00
<b>XEROX DOUPRINT N24/32/40</b>			
22K48230-GEN	XEROX N24/32/40	Transfer Roller, W/Gear	5.72
600K61600	XEROX N24/32/40	Pick up Roller	2.00

UFP-W820	XEROX N24/32/40	Upper fuser Roller	9.74
LPR-W820	XEROX N24/32/40	Fuser Pressure Roller	16.84
SP-N40	XEROX N24/32/40	Separation Pad	2.00
<b>XEROX 3428</b>			
JC66-01211A	Xerox 3428	Upper fuser roller	8.40
JC66-01195A	Xerox 3428	Fuser pressure roller	11.02
JC97-02034A	Xerox 3428	Pick up poller tray2	2.00
JC61-01169A	Xerox 3428	Separation pad tray2	2.00
<b>XEROX 4500</b>			
059K03380	XEROX 4500	Upper Fuser Roller	9.00
UR-X4500	XEROX 4500	Lower Sleeve Roller	15.52
802K49746-GEN	XEROX 4500	Transfer Roller, W/Gear	4.62
013E22021	XEROX 4500	Bearing, Sleeve Roller	2.16
N/A	XEROX 4500	Heating lead	3.94
FG-X4500	XEROX 4500	Fuser Gear 48T	2.00
BSH-U4500	XEROX 4500	Bearing, Heat Roller	3.56
604k11192	XEROX 4500	Pick up Roller	2.00
<b>XEROX 4517</b>			
600K99290/63H2396	XEROX 4517	Transfer roller, W/Gear	4.94
GR-4517-12T	XEROX 4517	Fuser Gear 12T	2.00
GR-4517-15T	XEROX 4517	Fuser Gear 15T	2.00
GR-4517-35T	XEROX 4517	Fuser Gear 35T	2.00
LPR-4517-FX	XEROX 4517	Lower Sleeve Roller	9.38
<b>Brother HL 2040/2045</b>			
LPR-203A	HL 2045	Lower Sleeve Roller	8.34
UPR-203A	HL 2045	Upper Fuser Roller	7.70
<b>Brother HL 2060/1660</b>			

LPR-2060	HL 2060	Upper Fuser Roller	8.04
N/A	HL 2060	Lower sleeve roller	8.04
LPR-1660	HL 1660	Upper Fuser Roller	8.04
<b>Brother HL 2140</b>			
N/A	HL 2140	Fuser Pressure Roller	8.04
N/A	HL 2140	Upper Fuser Roller	7.70
<b>Brother HL 2240/2230</b>			
N/A	HL 2240/2230	Lower sleeve roller	8.04
N/A	HL 2240/2230	Upper Fuser Roller	7.04
<b>Brother HL 5140</b>			
N/A	HL 5140	Fuser Pressure Roller	8.10
N/A	HL 5140	Upper Fuser Roller	7.80
<b>Brother HL 5240</b>			
N/A	HL 5240	Fuser Pressure Roller	8.10
N/A	HL 5240	Upper Fuser Roller	7.80
<b>HL 5340/5370</b>			
N/A	HL 5340/5370	Fuser Pressure Roller	8.10
N/A	HL 5340/5370	Upper Fuser Roller	7.80
<b>HL 5440</b>			
N/A	HL 5440	Fuser Pressure Roller	12.20
N/A	HL 5440	Fuser Film Sleeve(Japanese material)	25.00
<b>HL 7860/7030</b>			
N/A	HL 7860/7030	Fuser Pressure Roller	8.10
N/A	HL 7860/7030	Upper Fuser Roller	7.80
<b>DCP8060/8065</b>			
N/A	DCP8060/8065	Fuser Pressure Roller	8.10
N/A	DCP8060/8065	Upper Fuser Roller	7.80

<b>MFC8480/8680/8890</b>			
N/A	MFC8480/8680/8890	Fuser Pressure Roller	8.10
N/A	MFC8480/8680/8890	Upper Fuser Roller	7.80
<b>MFC8460/8660/8670/8860/8870</b>			
N/A	MFC8460/8660/8670/8860/8870	Fuser Pressure Roller	8.10
N/A	MFC8460/8660/8670/8860/8870	Upper Fuser Roller	7.80
<b>Minolta QMS2060</b>			
0993-5501-01-GEN	QMS-2060	Upper Fuser Roller	7.76
0993-5502-01-GEN	QMS-2060	Lower Sleeved poller	13.52
0993-6702-01	QMS-2060	Heating lead	2.00
0993-5518-01	QMS-2060	Lower Picker Finger	2.00
0993-5535-01	QMS-2060	Bushing, heat Roller	2.00
0993-5521-01	QMS-2060	Bushing, Sleeve Roller	2.00
0993-5524-01	QMS-2060	Fuser Gear 15T	2.00
0993-5512-01	QMS-2060	Fuser Gear 15T	2.00
0933-5533-01.	QMS-2060	Bushing Roller	2.00
0993-5537-01	QMS-2060	Bushing Roller	2.00
0993-5534-01	QMS-2060	Bushing Roller	2.00
<b>CANON FAX-L120/L100</b>			
RC1-2038-000	CANON FAX-L120	Separation Pad	2.00
RC1-2048-000	CANON FAX-L120	Separation Pad	2.00
PS-1010-ASS	CANON FAX-L120	The paper rolling of	1.16
RC1-2050	CANON FAX-L120	Pick up Roller	1.00
RM1-0658-000	CANON FAX-L120	Transfer Roller, W/Gear	4.98
RC1-2094-000	CANON FAX-L120	Fuser Delivery Assy	1.56
RC1-2051-000	CANON FAX-L120	Delivery Roller	1.56
RU5-0184-000	CANON FAX-L120	Clutch Separation Roller	1.44

RM1-0648-000	CANON FAX-L120	Separation Assembly	1.62
RM1-1493-FM3	CANON FAX-L120	Fuser Film Sleeve(Japanese material)	1.56
RM1-0656-HEAT	CANON FAX-L120	Heating element 220V	6.94
RU5-0185-000	CANON FAX-L120	Fuer Gear 29T	1.00
RC1-2079-000	CANON FAX-L120	Bushing Pressure Roller	1.00
RM1-0660-000	CANON FAX-L120	Fuser Pressure Roller	6.70
<b>CANON LBP3018/3010/3050</b>			
RM1--3955-FM3	CANON LBP3018/3010/3050	Fuser Film Sleeve(Japanese material)	1.56
LPR-1008	CANON LBP3018/3010/3050	Fuser Pressure Roller	6.70
RM1-4023-000	CANON LBP3018/3010/3050	Transfer Roller	5.00
RM1-4006-000	CANON LBP3018/3010/3050	Separation Pad	1.62
RL1-1442-000	CANON LBP3018/3010/3050	Pick up Roller	1.00
<b>CANON MF-3220</b>			
RM1-0656-HEAT	CANON MF-3220	Heating element 220V	6.94
RM1-1461-FM3	CANON MF-3220	Fuser Film Sleeve(Japanese material)	1.56
LPR-3220	CANON MF-3220	Fuser Pressure Roller	6.70
<b>CANON</b>			
FB2-2282-FM3	NP6016	Fuser Film Sleeve(Japanese material)	42.76
FG6-6039-FM3	IR2200/2800/3300/2270/2230	Fuser Film Sleeve(Japanese material)	4.20
FB5-4942-000	IR2200/2800/3300	Fuser Pressure Roller	16.84
FB2-7777	Canon NP6050	Pickup Roller	3.58
FB2-7545	Canon NP6050	Pickup Roller	3.58
<b>Lenovo LJ2500/2313</b>			
N/A	LJ2500	Lower sleeve roller	10.00
N/A	LJ2500	Upper Fuser Roller	8.68
N/A	LJ2312	Lower sleeve roller	10.00
N/A	LJ2312	Upper Fuser Roller	8.68

<b>PANASONIC FP-503/523</b>			
N/A	FP-503/523/KX-FA76A/77A	Lower sleeve roller	7.70
N/A	FP-503/523/KX-FA76A/77A	Upper Fuser Roller	7.04
<b>DELL 1710/1720</b>			
LPR-1710	DELL1710/1720	Fuser pressure Roller	10.32
<b>IBM 1512</b>			
UFP-1512	IBM Infoprint 1512	Upper Fuser Roller	7.06
LPR-1512	IBM Infoprint 1512	Fuser Pressure Roller	9.40
56P1823	IBM Infoprint 1512	Transfer Roller	5.60
56P1820	IBM Infoprint 1512	Pick up Roller	1.00
<b>RIOCH C3002 C3502</b>			
D142-4083	RIOCH C3002 C3502	Fuser Film Sleeve	39.60